

# Service Manual

# Waterproof Indicator

# QW/GW with

# Multicolor Backlight

© Excell Precision Limited. All rights reserved Worldwide.

The information contained herein is the property of Excell Precision Limited and is supplied without liability for errors or omissions. No part may be reproduced or used except as authorised by contract or other written permission. The copyright and the foregoing restriction on reproduction and use extend to all media in which the information may be embodied.



6F, No. 127, Lane 235, Baoqiao Rd., Xindian District,  
New Taipei City 23145, Taiwan



pm-all@excell.com.tw



+886-2-8919-1000



<https://www.excell-scale.com>



+886-2-8919-2209

V24. 0814



# Table of Contents

Table of Contents .....	1
SPECIAL NOTICE .....	3
Before Using the Scale .....	4
Instruction for Use .....	4
Preparing to use the Scale .....	4
Quick Setup Calibration .....	6
Chapter 1 Introduction .....	7
1-1 Product Features.....	7
1-2 Specifications .....	7
1-3 Product Appearance.....	7
1-5 Power Supply .....	9
1-6 Keypad Function .....	10
1-7 Error Messages.....	12
1-8 Weight Units.....	13
1-9 Self-Test Mode .....	13
Chapter 2 Configurations .....	15
2-1 01 FnC General Function Setting.....	15
2-1-1 FnC 01 Auto Backlight .....	16
2-1-2 FnC 02 Auto Power-off Timer Setting.....	16
2-1-3 FnC 03 HI/LO/OK Settings .....	16
2-1-4 FnC 04 Restore to the Default Settings .....	17
2-1-5 FnC 05 Noise Filter Settings .....	17
2-1-6 FnC 06 Hold Function Settings .....	18
2-1-7 FnC 07 Auto Unit Weight Averaging Setting .....	20
2-1-8 FnC 10 Record Last Zero .....	20
2-1-9 FnC 11 Foot Switch Settings (Option) .....	20
2-1-10 FnC 12 <input checked="" type="checkbox"/> Key Function Settings .....	21
2-1-11 FnC 13 Zero Key Setting .....	21
2-1-12 FnC 14 Backlight Color Setting .....	21
2-1-13 FnC 15 Backlight Brightness Setting .....	21
2-2 02 EC External Weight Calibration .....	22
2-3 03 rS1 RS232 Serial Interface Settings.....	23
2-3-1 rS1 01 Baud Rate Settings .....	23
2-3-2 rS1 02 Communication Protocol Settings.....	23
2-3-3 rS1 03 Output Format Settings .....	24
2-3-4 rS1 04 Transmission Method .....	27
2-3-5 rS1 05 Continuous Transmission Rate .....	27
2-3-6 rS1 06 Zero Band Setting for Auto Transmission.....	27
2-3-7 rS1 07 Weight Band Setting for Auto Transmission.....	28
2-3-8 rS1 08 Output Condition Settings .....	28
2-3-9 rS1 09 RS232 6/7 Digits Setting .....	28
2-3-10 rS1 10 RTC Adjustment .....	29
2-3-11 rS1 11 Y/M/D Print Format .....	29
2-3-12 rS1 12 RS485 ID Input (Option) .....	29
2-3-13 rS1 13 Numbers of Line Feed for rS1 03 = 10 or 11 .....	29
Chapter 3 Service Mode Access .....	30
3-1 01 CSP Capacity Setup.....	31
3-1-1 CSP 01 Weight Unit Setting .....	32
3-1-2 CSP 02 Customised Capacity Setting .....	35



---

3-1-3 Myanmar (viss) specification parameter table .....	41
3-1-4 CSP 03 Multi-segment Setting .....	43
3-2 03 CLn Linearity Calibration .....	44
3-3 02 CAL Weight Calibration .....	47
3-3-1 CAL 01 Weight Calibration Setting .....	48
3-3-2 CAL 02 Manufacturing Location Gravity Setting .....	49
3-4 06 CGr Local Gravity Setting .....	50
3-5 04 CFn Function Setting .....	51
3-5-1 CFn 01 Environment Parameters .....	52
3-5-2 CFn 02 Approval Configuration .....	53
3-5-3 CFn 04 Initial Zero Setting .....	54
3-5-4 CFn 05 Hold Function Setting .....	55
3-5-5 CFn 06 Zero Tracking .....	57
3-5-6 CFn 07 Counting Function Setting .....	57
3-5-7 CFn 08 Tare Setting .....	57
Appendix 1 ASCII Code Table .....	58
Appendix 2 7-Segment Display Characters .....	58
Appendix 3 RS-232 Data Format .....	59
Appendix 4 Wiring Instructions .....	64

## Check Firmware Version

Turn off scale first. Hold **NET|GROSS** key and press **ON|OFF** key to turn on scale. Wait till display shows 01 AdC. Press **ZERO** key twice and display 03 VEr. Press **TARE|PT** key to display firmware version 02005. Press **TARE|PT** key again to display maintenance number 60X (X is ranged from 0~9) for 2 seconds. Turn off and turn on scale to return to weighing mode.



## SPECIAL NOTICE


While installing the load cell, power cord hookup or replacing a new rechargeable battery, the indicator housing must be opened. It must be done by a technician assigned by your electronic indicator provider to avoid affecting the waterproof ability of this indicator. Before opening the housing, make sure the indicator is dry, if there is any liquid on it, please wipe it with a clean cloth.

### How to INSTALL THE HOUSING:


After installing the load cell, power cord hookup or replacing a new rechargeable battery, the housing must be screwed by the assigned order as shown below. Screw lightly first, then screw them tight using a 6 kgf-cm (GW) or 12 kgf-cm (QW) torsion.

P.s. Please use a torsion-adjustable screw driver.

Screwing order:




▲ GW




▲ GW

### ▼ How to Install U-Bracket



▲ QW



M8 Recommended  
Screws are **NOT** included



Thank you for purchasing EXCELL WEIGHING INDICATOR, to help use the product properly, operate smoothly, and extend its life cycle, please read this manual carefully.

## Before Using the Scale

In order to use this scale correctly, we suggest that you read this manual carefully.

### Instruction for Use

1. The load placed on the weigh pan must NOT exceed the maximum weighing capacity of the scale.
2. Protect the scale from high temperatures.
3. Avoid objects impacting with the scale. Do not drop loads onto the scale or subject the weigh pan to any strong shock loads.

### Preparing to use the Scale

1. Locate the scale on a firm level surface free from vibrations for accurate weight readings.
2. Adjust the four levelling feet (if fitted) to set the scale pan level.
3. Avoid operating the scale in direct sunlight or drafts of any kind.
4. If possible avoid connecting the scale to ac power outlet sockets which are adjacent to other appliances to minimise the possibility of interference affecting the performance of the scale.
5. Remove any weight that might be on the weigh pan before the scale is switched on and avoid leaving weight on the pan for long periods of time
6. All goods weighed should be placed in the centre of the weigh pan for accurate weighing. The overall dimensions of the goods being weighed should not exceed the dimension of the weigh pan.
7. Once the scale has been powered on, it will go through an LCD display test and it is ready for use when the display shows zero.
8. The scale requires 15~20 minutes warm up before operation to ensure best accuracy
9. Please note when the symbol keeps flashing on the screen, the batteries need to be recharged.
10. Introduction of Storage Battery




Due to the storage battery adopt the advanced free-maintaining technique, customers need not to replenish electrolyte.

The scale should be recharged every 3 months to prevent failure of the internal rechargeable battery.

1. The battery should be charged for 8~10 hours.
2. The temperature of battery should below 45°C.

## Maintaining

1. Please do not discharge with over-current when using the battery. Please charge the battery after discharging current.
2. Please take down the battery when the scale is not used for a long time or break the connection of cathode.
3. Do not short the battery terminals to check whether there is current. Please check whether the connection point is firm to guarantee good connection.
4. The battery should be replaced by specialized person. **No reverse-battery or the product will be damaged.**
  - a) Anode of battery should be connected with Anode of product battery (usually red cable)
  - b) Cathode of battery should be connected with Cathode of product battery (usually brown cable or black cable)
  - c) See the picture following



## Safety Warnings !

1. The electrolyte of battery is caustic which causes metal, cotton, etc. to corrode.
2. The hydrogen will be resolved when using or charging the battery and it will cause explosion when approaches fire.



No burning



Caution Corrosion



Warning Explosion



Children Faraway



# Quick Setup Calibration

This page is to quickly initiate the scale, for the other functions configuration, you can refer the chapters below.

## Instructions:

### Step 1 :

- Power off the scale and open the case, find the mini-jumper SWA1 on the main board.
- Switch SWA1 to the ADJ position (EEPROM UNLOCKED) and then turn the power on.  
The display will show 01 CSP.

### Step 2 :

- Refer to the chapter 3-1 to complete Capacity Setup.

01 CSP

### Step 3 :

- Refer to the chapter 3-2 to complete Linearity Calibration.

03 CLn

### Step 4 :

- Refer to the chapter 3-3 to complete Weight Calibration.

02 CAL

### Step 5 :

- When done the initiation, switch the jumper SWA1 back to the LOCK position.

- ☞ If the jumper SWA1 is switched to the LOCK position during calibration, the machine will exit the service mode automatically.



# Chapter 1 Introduction

## 1-1 Product Features



- Extra-large and wide LCD display (175 x 70mm) 6 digits with 55mm height for easy weight reading
- Multi-color backlight
- QW with 304 stainless steel housing while GW with plastic ABS housing.
- Sealed to IP68, Waterproof, mist-proof and dustproof (Only use cables of 3mm~5mm diameter to ensure correct sealing of the cable glands)
- Large buttons easy to access and control.
- Kilogram (kg) and pound (lb) weighing modes
- Full range tare; Pre-tare; Auto zero tracking; Sampling counting
- Gross/Net indication
- Hold function; Check mode Lo/Hi/OK with multi-color backlight; Auto average unit weight
- Adjustable gravity value
- Low power indication and auto power off
- AC/DC power in and rechargeable battery
- Built-in RS-232
- Options:
  - One of RS-485, WIFI, Bluetooth,
  - Pressure release valve,
  - Foot switch

## 1-2 Specifications

- Analogue Input: Input Sensitivity  $0.2\mu\text{V}/\text{d}$  (Min.)
- Input Signal Range: -1mV~+14mV
- Input Zero Range: -1mV~+5mV
- Load Cell Excitation: 5V DC
- Load Cell Drive Capacity: Up to 8 x  $350\Omega$  load cells
- Non-linearity: 0.01% of full scale
- A/D Resolution: 500,000 counts (Maximum)
- Operating temperature: -10°C ~ +40°C


## 1-3 Product Appearance

232 mm


QW




[Standard]




GW



[Standard]




[Option]



RS-485 and foot switch are options



## 1-4 Display Description



- HI** : Upper limit
- OK** : Value between HI and LO
- LO** : Lower limit
- kg** : Unit "kilogram"
- lb** : Unit "pound"
- 斤** : HK tael or Taiwan Tael
- t** : Metric ton
- Pcs** : Counting mode indication
- 0←** : Zero point indication
- Net** : Net weight indication
- : Low Power indication

### Non-approval model:

▼ 1	:	(STABLE) stable indication
▼ 2	:	(GROSS) gross weight indication
▼ 3	:	( ) insufficient unit weight
▼ 4	:	( PT ) pre-tare indication
▼ 5	:	(Hold) weight hold indication
▼ 6	:	"M+" indication or "GN", "dwt", "carat" unit indication
▼ 7	:	Blank or "oz" or "viss" unit indication (set as needed)

### Approval model:

▼ 1	:	(STABLE) stable indication
▼ 2	:	(GROSS) gross weight indication
▼ 3	:	( ) insufficient unit weight
▼ 4	:	( PT ) pre-tare indication
▼ 5	:	Range 2
▼ 6	:	Range 1
▼ 7	:	M+

## 1-5 Power Supply

Power	Battery	6V 4Ah Rechargeable battery			
	Plugged in	100V~230V AC			
Power consumption (mA) with 1X350Ω load cell	No backlight	30~35			
	White backlight	100%	75%	50%	25%
		140	105	80	55
	Yellow backlight	96			
	Green backlight	62			
	Red backlight	66			

### Charging Voltage

DC 12V/1A adaptor



## Battery Status and Low Battery Warning



Normal battery status: The ( ) symbol is displayed steadily, indicating current battery status from 1 block ( ) to 4 blocks ( ).

- When the battery status indication is full, the power is about 6.4V; Each block is about 0.2V increment/decrement.



Low battery warning: When the ( ) symbol keeps flashing on the display (the remaining power is about 5.6V), the internal battery should be recharged.

- The scale will turn off automatically after a period of nonuse when the low battery warning symbol shows up. The scale must be fully charged, before operating again.

### Safety Reminder:

- Please make sure “+”, “-” poles are placed in the correct direction
- Please don’t place the battery in hot areas, or try to disassemble the battery, to avoid electricity leakage.
- The battery inside the indicator was used for testing the fullness of the product. Therefore, the life of the battery cannot be counted from the day you purchase.

## 1-6 Keypad Function

### **[ON|OFF] KEY**

Press the [ON|OFF] key to switch the indicator on or off.

### **[UNIT] KEY**

Press the [UNIT] key to switch weight units; the display icons will indicate the active units.

- After scale is powered on, scale uses the last used weighing unit.

### **[ZERO] KEY**

The [ZERO] key acts as the zero balance function. If the weighing value is within the range of zero balance, it can be re-zeroed and tare cancelled.

- Zero Range : OIML&NTEP is ±2% F.S., and Sri Lanka is ±3% F.S.

### **[M+|PRINT] KEY**

Totalization function. M+/Print function is available when RS232 is on keypad transmission mode. (rS1 04 output).

This key is a composite key, while totalization is shown and weight returns to net zero, press M+ key to erase memory. RS232 will output MC print format (rS1 03 output).

- If there is new weight added on platter (it is less than 20 divisions in Brazil version, no accumulation), a new item will be added to totalization. If this weight is not taken off, nothing can be added to totalization. Display will show the totalization numbers for one second, then show net weight for one second, then the scale returns to the current weight, and prints out the last item for totalization.

- To clear totalization data, press M+ key to let display shows up totalization numbers, then press the [M+|PRINT] key again, to clear totalization data. RS232 will print out totalization numbers, total weight, etc.


P.s. Weight must return to net zero if to perform clear function.

**TARE|PT** KEY: Tare / Pre-tare keyTo TARE:

Place the container onto the scale, until the weight value is stable, press **TARE|PT** key for zero return and the NET indication is shown on the display. Place the object onto the container and the display shows the net weight value of the object. Remove both object and container, and negative value of the container will show on the display. Press **TARE|PT** key again to clear "tare value". The scale returns to zero and NET indication goes off.

- Tare can be continuously done until tare value=full load capacity
- Continuous Tare → Press **TARE|PT** key for continuous weight increase/decrease on platter.
- If there is Tare, the pre-tare cannot be done. If there is pre-tare first, and the tare weight more than pre-tare weight, Tare can be done.
- No Tare can be done under gross weight display mode.

**NET|GROSS** KEY: In the Tare mode, "Net weight" shows on the display and "NET" icon is on; press the **NET|GROSS** key to switch to display "Gross weight". "GROSS" arrow ↓ shows up and only **NET|GROSS** key works here. All other keys become inactive. Gross Weight = Tare weight + Net weight.

To PRE-TARE:

Both types of Pre-tares can be cancelled by press **TARE|PT** key when no load.



**F KEY (Non approval models. For approval models, use F/H key instead)**

Before using this key, need to go to FnC 12 to set **F** key as the following function.

“MC” (Memory Clear) key: press it to erase memory directly without display the tantalization data. RS232 will output MC print format (rS1 03 output). Note: Weight must return to net zero if to perform clear function.

“HR” (High Resolution) key: press it to display 10 times resolution for 10 seconds and then return to normal resolution. If the original resolution is > 6000, “High Resolution” is not recommended since the reading might be unstable or the number of digits exceed display range.

“T-TP” key: press it to display Tare or Pre-tare value for 2 seconds if they exist and then return to current weight resolution. If both exit, it will display Pre-tare value and then display Tare value.

## Foot Switch Mode

This function is optional. Use FnC 11 to select **TARE|PT** key as “ZERO” or “PRINT” key

- If “PRINT” key is set (rS1 03 = 10 or 11), all totalization data will be printed out, and totalization will be cleared.
- If it is Brazil version and foot switch is set as Print function, it has totalization function and print function.

## Simple Counting Mode

Use **UNIT** key to switch unit to Pcs, to go into simple counting mode.

1. Use **NET|GROSS** key (For approval models, use **NET|B/G** key instead), to select a sample number from “10, 20, 50, 100, or 200”. Display will show **L 10, L 20, L 50, L 100, L 200** in an sequential order by pressing **NET|GROSS** key (For approval models, use **NET|B/G** key instead).
2. Select a sampling number, and put appropriate weight on platter, and press **UNIT** key. Display will show “— — — — —”. The scale will go into counting mode after weight is stable, and display will show the sample number.
  - Unit weight insufficient (**P<sub>os</sub>**): Sample unit weight is **less** than 0.2d or total sample weight is **less** than 20d (d=division)
  - While sampling, if there is insufficient sample or unit weight insufficient indication “▼”, the scale is still usable, but there may be slight inaccuracy.
  - After Power-off, the scale automatically memorizes the sampling number, and it is available when “Pcs” unit is selected next time.
  - If the setting is “automatic average unit weight”, if the object on platter > the previous sampling number more than 5 pcs, and also < less than 100% the previous sampling number, the scale will execute unit weight calibration automatically.

## 1-7 Error Messages

- E0** ⇒ The EEPROM is not working correctly.  
The EEPROM is not set yet, or the circuit on PCB is broken.
- E1** ⇒ Zero is higher than the zero range when switching the indicator on.
- E2** ⇒ Zero is lower than the zero range when switching the indicator on.
- E4** ⇒ A/D value is unstable.
- OL** ⇒ The weight of the object is over 9 divisions of the maximum capacity.
- **OL** ⇒ The weight of the object is under -1/6 maximum capacity.
- OF** ⇒ ADIC value is over the maximum range.



**E10** ⇒ The scale is not in level status. (Only if level detector equipped)

### Level Switch and E10 (option)

To use level switch, make J14 on PCB open circuited, display shows E10 and all keys stop working in the meantime. If J14 on PCB is short circuited, all functions work normally.


When level switch is used, and it is in level, a short circuited signal sends to CN6 and all functions work normally. If platform is tilted and not in level, an open circuited signal sends to CN6, and display shows E10 and all keys stop working.

## 1-8 Weight Units

kg	1 g = 0.001 kg	GN	1 g = 15.432358 GN
g	1 g = 1 g	dwt	1 g = 0.6430149 dwt
lb	1 g = 0.002204623 lb	ct	1 g = 5 ct
lb/oz	1 g = 0.03527396 oz	hk.tael	1 g = 0.02645546 Hk.catty
oz	1 g = 0.03527396 oz	viss	1kg = 0.612245 viss

## 1-9 Self-Test Mode

Turn off scale first. Hold **NET|GROSS** key (For approval models, use **NET|B/G** key instead), and press **ON|OFF** key to turn on scale. Wait till display shows 01 AdC to enter "Self-Test Mode".



### 01 AdC INTERNAL VALUE MODE (must hook up full-bridge Load Cell to test)

- ① Press **TARE|PT** key to enter, and the display shows internal value
- ② Please check the internal value is within normal range is 0 ~ 400000 (no load)
- ③ Check whether the backlight is on
- ④ Press **ZERO** key to back to the last screen, the display shows 01 AdC

### 02 KEY KEYPAD TEST MODE

- ① Press **TARE|PT** key to enter, display shows KEY 06  
Keypad's internal code: **TARE|PT** key = 06, **UNIT** key= 05,  
**NET|B/G** or **NET|GROSS** key=04   **M+|PRINT** key = 03,   **F** key = 02
- ② Press **ZERO** key to back to the last screen , the display shows 02 KEY



EXCELL® EXCELL PRECISION CO., LTD

## 03 Ⓛ FIRMWARE VERSION DISPLAY MODE

- ① Press [TARE|PT] key to display firmware version 02005
- ② Press [TARE|PT] key again to display maintenance number 60X (X is ranged from 0~9) for 2 seconds
- ③ Press [ZERO] key to back to the last screen, display shows 03 Ⓛ


## 00 Ⓛ BACK TO THE LAST SCREEN

Press [TARE|PT] key to exit self-test mode, the scale will re-power on automatically.



## Chapter 2 Configurations


In the weighing mode, press **[NET|GROSS]** key (For approval models, use **[NET|B/G]** key instead) and **[ZERO]** keys at the same time to enter the configuration mode. The LCD shows 01 FnC.



01 FnC ⇒ General Function Setting  
02 EC ⇒ External Weight Calibration  
03 rS1 ⇒ RS232 Bi-direction Function Setting  
00 ESC ⇒ Exit

Refer to the following sections for the detailed of each setting.

### 2-1 01 FnC General Function Setting



**ZERO** key ⇒ Upward key (0~9 digit entry)

**UNIT** key ⇒ Downward key (0~9 digit entry)

**TARE|PT** key ⇒ Move cursor rightward


**NET|GROSS** key ⇒ Move cursor leftward

(For approval models, use **[NET|B/G]** key instead)

FnC 00 ⇒ Return to to previous level  
FnC 01 ⇒ Automatic Backlight  
FnC 02 ⇒ Automatic Power-off Timer Settings  
FnC 03 ⇒ Hi/Lo/OK Settings  
FnC 04 ⇒ Restore the Default Settings  
FnC 05 ⇒ Noise Filter Settings  
FnC 06 ⇒ Hold Function Settings  
FnC 07 ⇒ Auto Unit Weight Averaging Setting  
FnC 08 ⇒ Reserved  
FnC 09 ⇒ Reserved  
FnC 10 ⇒ Record Last Zero  
FnC 11 ⇒ Foot switch on/off settings (Option)  
FnC 12 ⇒ **F** key function settings  
FnC 13 ⇒ Zero Setting  
FnC 14 ⇒ Backlight Color Setting  
FnC 15 ⇒ Backlight Brightness Setting



## 2-1-1 FnC 01 Auto Backlight




Display the last used value  
 ➤ Default setting = oFF  
 Use ZERO or UNIT key to select  
 on → backlight on  
 Auto → automatic backlight  
 oFF → backlight off

### Auto backlight function

When weight > 10d or any key is pressed, backlight is turned on. When weight < 10d or no key is pressed for 10 seconds, backlight is switched off.

## 2-1-2 FnC 02 Auto Power-off Timer Setting



Display the last used value  
 Default setting = 0 (No auto power-off)

### Automatic power-off timer setting


Use ZERO or UNIT key to select  
 0 ⇒ No auto power-off  
 1 ⇒ Switch scale off if idle for 1 minute  
 2 ⇒ Switch scale off if idle for 2 minute  
 ...  
 9 ⇒ Switch scale off if idle for 9 minute

### Auto power-off

When weight < 10d, and scale is idle longer than selected duration, the scale automatically switches off.

## 2-1-3 FnC 03 HI/LO/OK Settings

When the high limit and low limit are both set as "0", the Hi/Lo/OK function is disabled.



Display the last used value  
 Enter the high limit value and Press TARE|PT key

Display the last used value  
 Enter the low limit value and Press TARE|PT key

Display the last used value

### Alarm setting

00000b  
 (a)(b)(c)

The definition of a, b, c positions:

(a) ⇒ 1 = alarm on  
 0 = alarm off


(b) ⇒ 1 = alarm when stable  
 0 = alarm even when unstable

(c) ⇒ 1 = alarm when weight is between high and low limits  
 0 = alarm when weight > high limit or  
 when 10d < weight < low limit



■ If backlight is on, yellow backlight is for Low value, green backlight for OK value, and red backlight for High value.

## 2-1-4 FnC 04 Restore to the Default Settings



Use **ZERO** or **UNIT** keys to select “rEturn” or “ForMat”  
**rEturn** ⇒ Return (Cancel the restoration)  
**ForMat** ⇒ Restore to default setting


■ The following settings will be restored to their default values:

- 1) External weight calibration
- 2) HI/LO/OK setting values
- 3) Noise filter setting (External)
- 4) Sampling settings for the counting function

■ Approval model has no access to FnC 04

## 2-1-5 FnC 05 Noise Filter Settings

■ When modifying FnC 05, the parameters of CFn 01 remain un-altered.



### Zero display setting

Display the last used value.

Use **ZERO** or **UNIT** key to select 0~9. Default = 0.

Activate when weight is over 1/3 max and when object is removed and display is approaching 0. When approaching within  $0 \pm$  selected value, weight display 0.

0 ⇒ 0	4 ⇒ ± 4d	7 ⇒ ± 7d
1 ⇒ ± 1d	5 ⇒ ± 5d	8 ⇒ ± 8d
2 ⇒ ± 2d	6 ⇒ ± 6d	9 ⇒ ± 9d
3 ⇒ ± 3d		

### Digital switch & Stabilization range setting

Display the last used value.

Use **ZERO** or **UNIT** keys to select 0~9. Default = 0

The larger value: become stable more quickly.

### Filter parameter setting

Display the last used value.

Use **ZERO** or **UNIT** keys to select 0 ~ 9. Default = 5.

The larger value: faster response; therefore, more unstable.

If set to 9, AD value is not filtered.

Input AD value = Output AD value

■ Approval model has no access to FnC 05

**ZERO** key ⇒ Upward key (0~9 digit entry)

**UNIT** key ⇒ Downward key (0~9 digit entry)

**TARE|PT** key ⇒ Move cursor rightward


**NET|GROSS** key ⇒ Move cursor leftward

(For approval models, use **NET|B/G** key instead)



## 2-1-6 FnC 06 Hold Function Settings

When CFn 02 =1 (OIML or NTEP approval), FnC 06 is fixed to hold=0 and cannot be changed



### Hold function setting

Display the last used value

Use **ZERO** or **UNIT** keys to select 0~5

➤ Default setting = 0

0 ⇒ Hold function disabled

1 ⇒ "Peak hold" mode

2 ⇒ "Stable hold 1" mode

3 ⇒ "Stable hold 2" mode

4 ⇒ "Animal scale hold 1" mode

5 ⇒ "Animal scale hold 2" mode

hoLd 0 = Hold is disabled

hoLd 1 = "Peak hold" mode: Hold peak weight on the display until a key is pressed to release hold and get a new peak weight.

hoLd 2 = "Stable hold 1" mode: When the weight is stable, Hold the current stable weight until a key is pressed to release hold and get a new stable weight.

hoLd 3 = "Stable hold 2" mode: When the weight is stable, Hold the current stable weight until weight returns to zero (<10d), the hold is cancelled automatically.

hoLd 4 = "Animal scale hold 1" mode

When no load, display "-----". After the animal is on the platter and the weight is stable, the display Hold the current stable weight value. When the animal is off the platter, the display "-----" and the hold is released. If the weight is hardly stable, display Hold the average weight in 10 seconds until the weight < 10e and display shows "-----" or press any key to calculate a new weight.

hoLd 5 = "Animal scale hold 2" mode

When no load, display "0.000". After the animal is on the platter and the weight is stable, display Hold the current stable weight value. When the weight added or removed on the platter is > the hold range set in hold 5, hold is released and calculate a new hold weight. If the weight is hardly stable, display Hold the average weight in 10 seconds. **ZERO** and **TARE|PT** keys are inactive here. Hold lock speed can be set through SPEEd setting. "1" is the fastest and "5" is the slowest.

**Animal scale hold 1 hold 4**Press **TARE|PT** key

hold 4

**Hold function setting**

Display the last used value

Use **ZERO** or **UNIT** key to select 4.Press **TARE|PT** key to enter the hold settingPress **TARE|PT** key

0 10 %

**Allowed tolerance range**Use **ZERO** or **UNIT** keys to enter value (1%~100%)

Default setting = 10%

Press **TARE|PT** key

8

**Number of counts for averaging**Use **ZERO** or **UNIT** keys enter value (1,2,4,8,16,32,64)

Default setting = 8

Press **TARE|PT** key

FnC 06

**Animal scale hold 2 hold 5**Press **TARE|PT** key

hold 5

**Hold function setting**

Display the last used value

Use **ZERO** or **UNIT** key to select 5.Press **TARE|PT** key to enter the hold settingPress **TARE|PT** key

SPEED 1

**Hold speed setting**

Display the last used value

Use **ZERO** or **UNIT** keys to enter value (1~5)

1: fastest; 5: slowest

Press **TARE|PT** key

30.00 kg

**Hold range setting**

Display the last used value

Use **ZERO** or **UNIT** keys to enter value (0 ~ max capacity)Press **TARE|PT** key

FnC 06

**ZERO** key ⇒ Upward key (0~9 digit entry)**UNIT** key ⇒ Downward key (0~9 digit entry)**TARE|PT** key ⇒ Move cursor rightward**NET|GROSS** key ⇒ Move cursor leftward(For approval models, use **NET|B/G** key instead)

When weight returns to zero, Hold is released

After weight is HOLD, Hold is released only when weight change is more than  $\pm$  Hold range.


For example: if Hold range = 1 kg. Weight is held

at 8.5kg after buzzer sounds. When weight changes outside the range of  $8.5 \pm 1$ kg, for example, when weight is > 9.5kg or < 7.5kg, HOLD is released and until new HOLD weight is re-captured (displays weight changes until it enters HOLD).

Repeat to test the same animal for more than 10 times to compare the errors. Then finalize the Hold speed and Hold range setting.



## 2-1-7 FnC 07 Auto Unit Weight Averaging Setting



### Auto unit weight averaging setting

Display the last used value  
Use **ZERO** or **UNIT** key to select 0~1.

- Default setting = 0
- 0 ⇒ Enable Auto unit weight averaging
- 1 ⇒ Disable auto unit weight averaging

**ZERO** key ⇒ Upward key (0~9 digit entry)


**UNIT** key ⇒ Downward key (0~9 digit entry)

**TARE|PT** key ⇒ Move cursor rightward

**NET|GROSS** key ⇒ Move cursor leftward

(For approval models, use **NET|B/G** key instead)

## 2-1-8 FnC 10 Record Last Zero




### Record Last Zero

Display the last used value  
Use **ZERO** or **UNIT** key to select on or oFF.

- Default setting = oFF
- on ⇒ Enable Record the last zero
- oFF ⇒ Disable Record the last zero

FnC 10 is only for non-approval where CFn 02 = 0

## 2-1-9 FnC 11 Foot Switch Settings (Option)



### Foot switch function

Display the last used value

Use **ZERO** or **UNIT** key to select Foot switch as ZEro, tArE, or Print key.

ZEro ⇒ as **1ZERO** key

tArE ⇒ as **1TARE** key


Print ⇒ as **PRINT** key, use to send data through RS232

- 1) When rS1 03 = 10 or 11, after printing final total summary, it will clear totalization data.
- 2) When set to Brazil (CFn02=4) and rS1 04 = **R\_PLJ5**, print rS1 03 format with totalization function.



## 2-1-10 FnC 12 [F] Key Function Settings

(For approval models, use **F/H** key instead)



### Foot switch function

Display the last used value


Use **ZERO** or **UNIT** key to select **F** key as MC, hr or t-tP.

MC ⇒ as **MC** key: Press **MC** when weight returns to 0 to clear all totalization data

hr ⇒ as **HR** key: Press **HR** to switch to high resolution display for 5 seconds.

t-tP ⇒ select “t-tP” to display tare weight or Pre-tare weight for 2 seconds, and then returns to net weight. If both tare and Pre-tare weight exist, display tare weight first and then Pre-tare weight.

## 2-1-11 FnC 13 Zero Key Setting



### Unrestricted zero key range setting

Display the last used value

Use **ZERO** or **UNIT** key to select on or oFF.


➤ Default setting = oFF

on ⇒ Enable, zero for any weight

oFF ⇒ Disable

☞ FnC 13 is only for non-approval where CFn 02 = 0

## 2-1-12 FnC 14 Backlight Color Setting



### Backlight color setting


Display the last used value

Use **ZERO** or **UNIT** key to select W, r G, y for backlight.

□ ⇒ W for white □ ⇒ r for red

□ ⇒ G for green □ ⇒ y for yellow

## 2-1-13 FnC 15 Backlight Brightness Setting



### Backlight brightness setting

Display the last used value

Use **ZERO** or **UNIT** key to select 1~4.

1: dimmest 4:brightness



## 2-2 02 EC External Weight Calibration

02 EC

Press **TARE|PT** key, the display shows the calibration value. The right digit keeps flashing.

☞ The calibration weight could be changed

0030.00 kg

When the right digit is flashing, Press **TARE|PT** key while there is no load on platter

Press **NET|GROSS** key to move the flashing digit to the left.

Press **NET|GROSS** key to skip

0030.00 kg

Reading Zero. Once becomes stable displays the max weight.

30.00 kg

Put the calibrated weight on platter and press **TARE|PT** key; After 3 beep sounds, calibration completes; Remove weight

About 2 seconds later

Press **NET|GROSS** key to exit

SPRSS

About 2 seconds later

02 EC


☞ 02 EC is only for non-approval models

☞ The conditions for external weight calibration:

The calibrated weight > 100e, and the must be within  $\pm 10\%$  of factory's calibrated weight.




## 2-3 03 rS1 RS232 Serial Interface Settings



- rS1 00 ⇒ Return to previous level
- rS1 01 ⇒ Baud Rate Settings
- rS1 02 ⇒ Communication Protocol Settings
- rS1 03 ⇒ Output Format Settings
- rS1 04 ⇒ Transmission Method
- rS1 05 ⇒ Continuous Transmission Rate
- rS1 06 ⇒ Auto Transmission at Zero
- rS1 07 ⇒ Reset of Auto Transmission
- rS1 08 ⇒ Output Condition Settings
- rS1 09 ⇒ RS232 6/7 Digits Setting
- rS1 10 ⇒ RTC Adjustment
- rS1 11 ⇒ Y/M/D Print Format Selection
- rS1 12 ⇒ RS485 ID Input (Option)
- rS1 13 ⇒ Line Feed Input

### 2-3-1 rS1 01 Baud Rate Settings



#### Baud rate setting


Display the last used value

Use **ZERO** or **UNIT** key to select the desired Baud rate  
600、1200、2400、4800、9600、19200 (bits/sec)

Default setting = 9600 (bits/sec)

☞ If Bluetooth is used, set to 9600 and “n 8 1” protocol

### 2-3-2 rS1 02 Communication Protocol Settings



#### Communication protocol setting

Display the last used value


Use **ZERO** or **UNIT** key to select n 8 1, E 7 1, O 7 1.  
Default setting = n 8 1

☞ If Bluetooth is used, set to 9600 and “n 8 1” protocol

<b>ZERO</b> key ⇒ Upward key (0~9 digit entry)
<b>UNIT</b> key ⇒ Downward key (0~9 digit entry)
<b>TARE PT</b> key ⇒ Move cursor rightward
<b>NET GROSS</b> key ⇒ Move cursor leftward
(For approval models, use <b>NET B/G</b> key instead)



## 2-3-3 rS1 03 Output Format Settings



### Communication protocol setting

Display the last used value

Use **ZERO** or **UNIT** key to select 0~20. Default = 0

0 ⇒ Synchronize with display

1 ⇒ Gross weight

2 ⇒ Net weight

3 ⇒ Synchronized in simple format

4 ⇒ Synchronized Gross weight in simple format

5 ⇒ Synchronized Net weight in simple format

6 ⇒ Hi/Lo/OK status + synchronized in simple format

7 ⇒ Hi/Lo/OK status + synchronized Gross weight in simple format

8 ⇒ Hi/Lo/OK status + synchronized Net weight in Simple format

9 ⇒ Tare weight

14 ⇒ Brazil printing format note 5

10 ⇒ **M+** Transmission 1 note 1

15 ⇒ Reserved

11 ⇒ **M+** Transmission 2 note 2

16 ⇒ Reserved

12 ⇒ Brazil printing format note 3

17 ⇒ KPZ printing format note 6

13 ⇒ Brazil printing format note 4

Format 10.11 are not available on counting mode

Format 12.13.14 are only for Brazil

### Note1: F - n 10 = M+ Transmission 1

Ticket No.

Date year/month/day & day/month/year (choose 1 out of 2 date formats)

Time

G

T (PT when only pre-tare, T when tare or both tare and pre-tare)

N

Total Net (This line will only print when data is erased, showing net weight total of every count)

When rS1 13 = 2 (default), 3 blank lines are inserted between data. After memory is cleared, a summary report of total records and weights will be printed and then insert 4 blank lines afterward.

To add company name, use F-M 18 format and set company name in rS1 14 (see note 7).

### Note2: F - n 11 = M+ Transmission 2

Ticket No.

Date year/month/day & day/month/year (choose 1 out of 2 date formats)

Time

G

T (PT when only pre-tare, T when tare or both tare and pre-tare)

N

Total Weight (This line will only print when data is erased, showing gross weight total of every count)

When rS1 13 = 2 (default), 3 blank lines are inserted between data. After memory is cleared, a summary report of total records and weights will be printed and then insert 4 blank lines afterward.



**Note3:** F -  $\bar{5}$  12 = Brazil printing format

If it is not Brazil version, it can only print under continuous transmission.

If it is Brazil version, under decimal units mode, FnC 11 = Print and rS1 04 =  $\bar{5}_PLB$ , it can print out. It is not available on counting mode.

For example:

70.15Kg print as: =51.07000=51.07000=51.07000=51.07000=51.07000

negative 70.15Kg print as: =51.0700-=51.0700-=51.0700-=51.0700-

**Note4:** F -  $\bar{5}$  13 = Brazil printing format

If it is not Brazil version, it can print under key transmission, auto transmission and order mode.

If it is Brazil version, when the scale is stable and under decimal units mode,

FnC 11 = Print and rS1 04 =  $\bar{5}_PLB$ , it can print out.. It is not available on counting mode.

**Transmission format as followed:**

F	R	"	I	R	W	T	3	0	0	0	"	<LF>
?	<LF>											
G	G	G	,	G	G	<b>G</b>	<LF>					
T	T	T	,	T	T	<b>T</b>	<LF>					
N	N	N	,	N	N	<b>N</b>	<LF>					
A	A	A	,	A	A	<b>A</b>	<LF>					
C	C	C	C	C	C	<LF>						
D	D	/	M	M	/	Y	Y	<LF>				
H	H	:	m	m	:	S	S	<LF>				
n	n	n	,	n	n	<b>n</b>	t	t	t	, t	t a a a , a a a a c c c c c c c <LF>	
P	1	,	1	<LF>								

G = gross weight

T,t = tare

N,n = net weight

A,a = accumulating weight

C,c = accumulating times

D = date (DD/MM/YY) DD: day MM: month YY: year

H = time(HH:mm:ss) HH: hour mm: minute SS: second

For example:

tare 0.2kg, net weight 1key, press **M+**

FR"IRWT3000"

?

1,200

0,200

1,000

1,000

1

30/05/00

00:54:12

001,000000,200001,0000000001

P1,1

**Note5:** F -  $\bar{5}$  14 = Brazil printing format

If it is not Brazil version, it only can print under continuous transmission.

If it is Brazil version, under decimal units mode, FnC 11 = Print and rS1 04 =  $\bar{5}_PLB$ , it can print out. It is not available on counting mode.

**Transmission format as followed:**

S,GGG .GGG ,TTT .TTT,NNN.NNN

S = 0:stable 1:unstable

G = gross weight



T = tare + pre-tare

N = net weight

For example:

tare 1 kg, net weight 0.2key, gross weight 1.2 kg , stable, then show as followed:

0,001.200,001.000,000.200

Take off the weight then show as followed:

0,000.000,001.000,-01.000

**Note6:** F - R " W T 3 N " <LF> = KPZ printing format

Press **M+**, show the following format

F	R	"	W	T	3	N	"	<LF>
?	<LF>							
G	G	,	G	G	G	<LF>		
T	T	,	T	T	T	<LF>		
PT	PT	,	PT	PT	PT	<LF>		
N	N	,	N	N	N	<LF>		
pcs	pcs	pcs	pcs	pcs	pcs	<LF>		
N	N	N	N	N	N	T	T	T
p	1	,	1	<LF>				

G=gross weight, T=tare weight, PT=pre-tare weight, N=net weight, pcs=pieces (without decimal point)

Example:

PT 0.3 kg

T 0.7kg

G 1.2kg

N 0.2kg

Pcs 20

FR"WT3N"

?

1,200

0,700


0,300

0,200

20

000200000700000020

p1,1



Press **MC**, show the following format

F	R	"	5	2	0	T	"	<LF>
?	<LF>							
R	R	,	R	R	R	<LF>		
N	N	,	N	N	N	<LF>		
pcs	pcs	,	pcs	pcs	pcs	<LF>		
R	R	R	R	R	R	N	N	N N N
p	1	,	1	<LF>				

R=total number of totalized records, N=total net weight, pcs=total pieces (without decimal point)

FR"WT3N"

?

1

0,200

20

000001000200000020

p1,1



## 2-3-4 rS1 04 Transmission Method

Press TARE|PT key

Press TARE|PT key

Press TARE|PT key

### Transmission Method

Display the last used value

Use **ZERO** or **UNIT** key to select. Default = **Command**

**Command** = Command mode

**StreaM** = Continuous transmission

**Auto** = Auto transmit when stable

**rS1-OFF** = RS232 is off

**M+PLus** = M+ Mode

## 2-3-5 rS1 05 Continuous Transmission Rate

Press TARE|PT key

Press TARE|PT key

Press TARE|PT key

### Continuous transmission rate setting

Display the last used value

Use **ZERO** or **UNIT** key to select 1, 2, 4, 8, 16 or Max (times/sec). Default = 4

**ZERO** key ⇒ Upward key (0~9 digit entry)

**UNIT** key ⇒ Downward key (0~9 digit entry)

**TARE|PT** key ⇒ Move cursor rightward

**NET|GROSS** key ⇒ Move cursor leftward

(For approval models, use **NET|B/G** key instead)

## 2-3-6 rS1 06 Zero Band Setting for Auto Transmission

Press TARE|PT key

Press TARE|PT key

Press TARE|PT key

### Zero Band Setting for Auto Transmission

Display the last used value

To auto transmit once, weight must return < zero band first, and then place weight  $\geq$  zero band.

Use **ZERO** or **UNIT** key to select 00~99 d (d=increment) for zero band. Default = 05.

To auto transmit once, weight must return < zero band first, and then place weight  $\geq$  zero band.

■ If rS1 06 set to 00, when the scale is at zero and keeping stable, the data are keeping transmitted as "Continuous Transmission".



## 2-3-7 rS1 07 Weight Band Setting for Auto Transmission

Press TARE|PT key

5 - 6 00

Press TARE|PT key

### Weight Band Setting for Auto Transmission

Display the last used value

rs1 07 must be used with rs1 06. After data has been sent once and weight is not removed, to send data again, please keep adding weight until:  
weight is > zero band (rS1 06)+ weight band (rS1 07)

Use **ZERO** or **UNIT** key to select 00~99 d (d=increment) for weight band. Default = 00.

- If rS1 07 set to 00, when the scale is at zero and keeping stable, the data are keeping transmitted as "Continuous Transmission".

## 2-3-8 rS1 08 Output Condition Settings

Press TARE|PT key

Stb - P

Press TARE|PT key

### Output condition settings

Display the last used value

Use **ZERO** or **UNIT** key to select. Default = Stb - P.

All - P = Output always

Stb - P = Output when stable (No output when OL or unstable)

Stol - P = Output when stable (OL included)

**ZERO** key ⇒ Upward key (0~9 digit entry)

**UNIT** key ⇒ Downward key (0~9 digit entry)

**TARE|PT** key ⇒ Move cursor rightward

**NET|GROSS** key ⇒ Move cursor leftward

(For approval models, use **NET|B/G** key instead)

## 2-3-9 rS1 09 RS232 6/7 Digits Setting

Press TARE|PT key

5 . . .

Press TARE|PT key

### Output condition settings

Display the last used value

Use **ZERO** or **UNIT** key to select. Default = 5 . . .

5 . . . = 6 digits

5E6E = 7 digits



## 2-3-10 rS1 10 RTC Adjustment

The digital display shows the current date and time. The user is prompted to enter the last used value for each field (Year, Month, Day, Hour, Minute, Second) by pressing the **TARE|PT** key. The cursor moves right after each entry, and the **TARE|PT** key is used to save the value.

### Enter date in YY/MM/DD

Display the last used value

Use **ZERO** or **UNIT** key to select and use **TARE|PT** key to confirm and move cursor to the right. When cursor move to the rightmost end and press **TARE|PT** key to save.

### Enter time in HH/MM/SS

Display the last used value

Use **ZERO** or **UNIT** key to select and use **TARE|PT** key to confirm and move cursor to the right. When cursor move to the rightmost end and press **TARE|PT** key to save.

RTC adjustment is complete

## 2-3-11 rS1 11 Y/M/D Print Format

The digital display shows the current print format. The user is prompted to select the desired format (Y\_M\_d or d\_M\_Y) by pressing the **TARE|PT** key. The cursor moves right after each entry, and the **TARE|PT** key is used to save the value.

### Y/M/D Print Format

Display the last used value

Use **ZERO** or **UNIT** key to select.  
Y\_M\_d: print as Year/Month/Day  
d\_M\_Y: print as Day/Month/Year

**ZERO** key ⇒ Upward key (0~9 digit entry)

**UNIT** key ⇒ Downward key (0~9 digit entry)

**TARE|PT** key ⇒ Move cursor rightward

**NET|GROSS** key ⇒ Move cursor leftward

(For approval models, use **NET|B/G** key instead)

## 2-3-12 rS1 12 RS485 ID Input (Option)

The digital display shows the current RS485 ID. The user is prompted to enter the last used value by pressing the **TARE|PT** key. The cursor moves right after each entry, and the **TARE|PT** key is used to save the value.

### RS485 ID Input

Display the last used value

Use **ZERO** or **UNIT** key to select

## 2-3-13 rS1 13 Numbers of Line Feed for rS1 03 = 10 or 11

The digital display shows the current number of line feeds. The user is prompted to enter the last used value by pressing the **TARE|PT** key. The cursor moves right after each entry, and the **TARE|PT** key is used to save the value.

### Numbers of Line Feed for rs1 03 = 10 or 11

Display the last used value

Use **ZERO** or **UNIT** key to select. Default = 2.


When rS1 03 = 2, 3 blank lines are inserted between data. After memory is cleared, a summary report of total records and weights will be printed and then insert 4 blank lines afterward.



## Chapter 3 Service Mode Access

Open the case, then switch the mini-jumper SWA1 on the main board to the ADJ position (EEPROM UNLOCKED). Turn the power on. The display shows 01 CSP. When finished, set the jumper SWA1 back to the LOCK position. If the jumper SWA1 is returned to the LOCK position during calibration, the machine exits the service mode automatically.

The Service Mode Access contains 6 settings as below:



01 CSP ⇒ Capacity Setup

04 CF<sub>n</sub> ⇒ Function Setting

02 CAL ⇒ Weighing Calibration

05 CG<sub>r</sub> ⇒ Local Gravity Setting


03 CL<sub>n</sub> ⇒ Linearity Calibration

For non-approval model (CF<sub>n</sub> 02 = 0), following the steps below to enter service mode.

Hold **UNIT** key and press **ON/OFF** key to turn on the scale, until the screen shows **F4**. Press **TARE/PT** key to continue and input password 002011 and press **TARE/PT** key to enter service mode.



## 3-1 01 CSP Capacity Setup




**ZERO** key ⇒ Upward key (0~9 digit entry)  
**UNIT** key ⇒ Downward key (0~9 digit entry)  
**TARE|PT** key ⇒ Move cursor rightward  
**NET|GROSS** key ⇒ Move cursor leftward  
(For approval models, use **NET|B/G** key instead)

- |        |                                   |
|--------|-----------------------------------|
| CSP 00 | ⇒ Return to the Upper Level       |
| CSP 01 | ⇒ Weight Units Setting            |
| CSP 02 | ⇒ Customised Weight Units Setting |
| CSP 03 | ⇒ Multi-segment Setting           |



### 3-1-1 CSP 01 Weight Unit Setting

There is no resolution limitation when the weight units "kg, g, lb, lb/oz" are selected. The weight units "oz, GN, dwt, and ct" are only available on indicators with less 1/10,000 external resolution.





**NOTE 1** The users can set up the different weight units in various orders according to their preference, and the amount of the chosen weight units can be up to 5

0 0 0 0 0  
(a) (b) (c) (d) (e) (f)

- (a) ⇒ The first weight unit (only “kg”, “g”, or “lb” are available to choose from. Please select one of the parameters 0, 1, or 2)
- (b) ⇒ The second weight unit (select one of the parameters described below)
- (c) ⇒ The third weight unit (select one of the parameters described below)
- (d) ⇒ The fourth weight unit (select one of the parameters described below)
- (e) ⇒ The fifth weight unit (select one of the parameters described below)
- (f) ⇒ The amount of the weight units selected (select one of parameters 1 ~ 5)

The description of the parameters

0 ⇒ kg (Decimal system)	5 ⇒ oz (Decimal system)
1 ⇒ g (Decimal system)	6 ⇒ GN (Decimal system)
2 ⇒ lb (Decimal system)	7 ⇒ dwt (Decimal system)
4 ⇒ lb, oz (hexadecimal)	8 ⇒ ct (Decimal system)

For example:

Choose “kg” & “lb” (two weight units). NOTE the scale is calibrated using “kg” weights and key in 020002

**NOTE 2** Enter the maximum capacity of the scale, total 6 digits (not including 9d)

0 0 0 0 0  
(g) (h) (i) (j) (k) (l)

For example:

15.000 kg ⇒ key in 015000

1500.0 g ⇒ key in 015000

6.000 lb ⇒ key in 006000

**NOTE 3** Set the minimum division and decimal point position to determine the display resolution

0 0 0 0 0  
(m) (n) (o) (p) (q)

Division = m \* 10<sup>-n\*q</sup>, m = base value, n = numbers of decimal point,

q = multiplication factor

(m) ⇒ Division base value, select 1, 2, or 5

(n) ⇒ The number of decimal places (0 ~ 5)

For example: 15.000 kg ⇒ enter 3, 1500.0 g ⇒ enter 1, 6.000 lb ⇒ enter 3

(o) ⇒ range setting (select one of parameters 0, 1, 2, or 3)

For example:

0, 1 ⇒ full segment range, 2 ⇒ 2 segment range (divided at 1/2 of the full scale),

3 ⇒ 3 segment range (divided at 1/6 of the full scale & 2/3 of the full scale)

(p) ⇒ 0 : multi-interval      1 : multi-range




**Multi interval:** Multiple segment range and each segment with its own minimum and maximum capacity and scale interval. The selection of the appropriate weighing segment is determined automatically according to the load applied, both on increasing and decreasing loads.


**Multi range:** Similar to Multi-interval, but the scale interval unchanged when unloading until weight return to zero

2 Segment range:

Multi interval




Multi range




3 Segment range:

Multi interval



Multi range



(q) ⇒ Division multiplication factor: ( Only one Weight UNITS Model is available)

0 ⇒ no factor    1 ⇒ base value X 10


Division Table for various m and q values:


(m) = 1	(m) = 2	(m) = 5	(m) = 1	(m) = 2	(m) = 5
(q) = 0				(q) = 1	
1	2	5	10	20	50

>If 2 segment range and multi-range is set, tare automatically cancels out after weight is cleared.



### 3-1-2 CSP 02 Customised Capacity Setting





**NOTE 4**

0n 1t00  
(a) (b)

(a) ⇒ The number of the weight units (Max: 5, key in 1 ~ 5)

(b) ⇒ The weight unit for weight calibration (choose from "kg", "g", "lb", key in 0, 1, or 2)

Parameter description:

0 ⇒ kg , 1 ⇒ g , 2 ⇒ lb

**NOTE 5**

000001  
(c) (d) (e) (f) (g) (h)

000002  
(i) (j) (k) (l) (m) (n)

c ~ h set the maximum capacity (6 digits)

i ~ n set the mass value for weight calibration (6 digits)

The maximum capacity needs to be presented based on the decimal system, and the first unit must be the calibration unit.

**For example:** How to calculate the maximum capacity and the mass value based on the different types of weight unit.

**A. Choose "kg" as the weight unit for the weight calibration**

① The first weight unit setting: 6.000 kg / 0.002 kg

⇒ Enter the maximum capacity 006000 at (c) ~ (h)

⇒ Enter the mass value 006000 at (i) ~ (n)

② Unit "lb" (hexadecimal notation system)

Calibration weight is 6kg. 0.001 kg = 0.002204623 lb

6 kg =  $6 \times 2.204623$  (lb) = 13.227738 lb. Take 12 lb as the max capacity

12.00 lb / 0.08 oz (minimum division=8, decimal point position=2)

12 lb × 16 (oz) = 192.00 oz ⇒ Enter the maximum capacity 019200 at (c) ~ (h)

13.227738 lb × 16 (oz) = 211.64 oz ⇒ Enter the mass value 021164 at (i) ~ (n)

③ Unit "GN"

Calibration weight is 6kg. 0.001 kg = 15.432358GN

6kg=92594GN ⇒ Enter the calibration weight 092594 at (i) ~ (n)

The maximum capacity 100000GN ⇒ Enter the maximum capacity 100000 at (c) ~ (h)

**B. Choose "lb" (decimal notation system) as the weight unit for the weight calibration**

① The first weight unit setting: 12.000 lb / 0.005 lb (the maximum Capacity / division)

⇒ Enter the maximum capacity 012000 at (c) ~ (h)

⇒ Enter the mass value 012000 at (i) ~ (n)

② The second weight unit setting "g"

0.002204623 lb = 1 g

12 lb = 5443 g. Take 6000 g as the maximum capacity

6000 g / 2 g (the maximum Capacity / division),

⇒ Enter the maximum capacity 006000 at (c) ~ (h)

⇒ Enter the mass value 005443 at (i) ~ (n)

③ "lb/oz" (hexadecimal notation system):

12.00 lb / 0.05 oz (the maximum Capacity / division)

12 lb =  $12 \times 16$  (oz) = 192.00 oz



- ⇒ Enter the maximum capacity 019200 at (c) ~ (h)  
 ⇒ Enter the mass value 019200 at (i) ~ (n)

④ "oz" :

Calibration weigh 12 lb = 192.00 oz ,  
 Take 200.00 oz as the maximum capacity  
 200.00 oz / 0.05 oz (the maximum Capacity / division)  
 ⇒ Enter the maximum capacity 020000 at (c) ~ (h)  
 ⇒ Enter the mass value 019200 at (i) ~ (n)

⑤ "GN" :

Calibration weight 12 lb, 0.002204623 lb = 15.432358 GN  
 12 lb = 84000 GN, (1 GN = 0.06479891 g)  
 84000 GN / 10 GN,  
 ⇒ Enter the maximum capacity 084000 at (c) ~ (h)  
 ⇒ Enter the mass value 084000 at (i) ~ (n)

## NOTE 6

□ □ □ □ □ 3  
 (o) (p) (q) (r) (s) (t)

(o) ⇒ Minimum division setting

Parameter description:

Decimal system:

Input 1, 2, or 5 as the  
 minimum division for the  
 weight value

Hexadecimal notation system:

Input 1, 2, 4, or 8 as the  
 minimum division for the  
 weight value

(p) ⇒ Decimal point position

Parameter description:

Decimal system:

0 ⇒ 0  
 1 ⇒ 0.0  
 2 ⇒ 0.00  
 3 ⇒ 0.000  
 4 ⇒ 0.0000  
 5 ⇒ 0.00000

Hexadecimal notation system:

0 ⇒ 0.\_0  
 1 ⇒ 0.\_0.0  
 2 ⇒ 0.\_0.00  
 3 ⇒ 0.\_0.000

(q) ⇒ Weight unit displayed

Parameter	0	1	2	4	5	6	7	8
Unit	kg	g	lb	lb,oz	oz	GN	dwt	ct
Notation system	10	10	10	16	10	10	10	10
symbol	kg	g	lb	lb	Icon 7 ▼ indication	Icon 6 ▼ Indication	Icon 6 ▼ indication	Icon 6 ▼ indication

(r) ⇒ Scale change point (Input the parameter 0, 1, 2, or 3)

Parameter description:

0 ⇒ full range

1 ⇒ full range

2 ⇒ dual range (changes at 1/2 of full scale)

3 ⇒ triple range (changes at 1/6 of full scale and 2/3 of full scale)



(s) ⇒ Save the weight units at preferred slots (no more than the number of set weight units)

Parameter description:

1 ⇒ the first slot (the weight calibration unit)

2 ⇒ the second slot

3 ⇒ the third slot

4 ⇒ the fourth slot


5 ⇒ the fifth slot

(t) ⇒ 0: multi-interval     1: multi-range



# Customized Capacity Setting- How to Revise

To revise customized setting, please follow the steps below





### 3-1-3 Myanmar (viss) specification parameter table


3.0000kg/0.0002kg 6.0000lb/0.0005lb 1.8000viss/0.0001viss	3.0000kg/0.0002kg 6.0000lb/0.0005lb	1.8000viss/0.0001viss
	CSP 01	CSP 02
	020002	vn .t30
	030000	0 18000 ⇒ Max capacity 1.8000viss
	240000	0 18367 ⇒ 3kg= 1.8367viss
		145030
6.0000kg/0.0005kg 12.0000lb/0.001lb 3.6000viss/0.0002viss	6.0000kg/0.0005kg 12.0000lb/0.001lb	3.6000viss/0.0002viss
	CSP 01	CSP 02
	020002	vn .t30
	060000	036000 ⇒ Max capacity 3.6000viss
	540000	036734 ⇒ 6kg= 3.6734viss
		245030
15.000kg/0.001kg 30.000lb/0.002lb 9.0000viss/0.0005viss	15.000kg/0.001kg 30.000lb/0.002lb	9.0000viss/0.0005viss
	CSP 01	CSP 02
	020002	vn .t30
	0 15000	090000 ⇒ Max capacity 9.0000viss
	130000	09 1836 ⇒ 15kg= 9.1836viss
		545030
30.000kg/0.002kg 60.0000lb/0.005lb 18.000viss/0.001viss	30.000kg/0.002kg 60.0000lb/0.005lb	18.000viss/0.001viss
	CSP 01	CSP 02
	020002	vn .t30
	030000	0 18000 ⇒ Max capacity 18.000viss
	230000	0 18367 ⇒ 30kg= 18.367viss
		135030



60.000kg/0.005kg 120.00lb/0.01lb 36.000viss/0.002viss	60.000kg/0.005kg 120.00lb/0.01lb	36.000viss/0.002viss
	CSP 01	CSP 02
	020002	vn .t30
	060000	036000 ⇒ Max capacity 36.000viss
	530000	036734 ⇒ 3kg= 36.734viss
		235030
150.00kg/0.01kg 300.00lb/0.02lb 90.000viss/0.005viss	150.00kg/0.01kg 300.00lb/0.02lb	90.000viss/0.005viss
	CSP 01	CSP 02
	020002	vn .t30
	015000	090000 ⇒ Max capacity 90.000viss
	120000	09 1836 ⇒ 150kg= 91.836viss
		535030
300.00kg/0.02kg 600.00lb/0.05lb 180.00viss/0.01viss	300.00kg/0.02kg 600.00lb/0.05lb	180.00viss/0.01viss
	CSP 01	CSP 02
	020002	vn .t30
	030000	0 18000 ⇒ Max capacity 180.00viss
	220000	0 18367 ⇒
		125030
600.00kg/0.05kg 1200.0lb/0.1lb 360.00viss/0.02viss	600.00kg/0.05kg 1200.0lb/0.1lb	360.00viss/0.02viss
	CSP 01	CSP 02
	020002	vn .t30
	060000	036000 ⇒ Max capacity 360.00viss
	520000	036734 ⇒ 600kg= 367.34viss
		225030



### 3-1-4 CSP 03 Multi-segment Setting




- By the specification setting of CSP 02, CSP 01 the default separation points for the 2 segments model is 1/2 full scale, and 1/6 full scale and 2/3 full scale for the 3 segments model. To change the interval point setting, please use the CSP 03 function.
- After CSP 03 is set, if the specification settings of CSP 02 and CSP 01 have been changed, the separation points would be reset to the default setting.



## 3-2 03 CLn Linearity Calibration

- After linearity calibration, it is necessary to re-calibrate the weight.
- Weight calibration should be included in linearity calibration.



<b>ZERO</b> key	⇒ Upward key (0~9 digit entry)
<b>UNIT</b> key	⇒ Downward key (0~9 digit entry)
<b>TARE PT</b> key	⇒ Move cursor rightward
<b>NET GROSS</b> key	⇒ Move cursor leftward

(For approval models, use **NET|B/G** key instead)



### Weight factor

The weight factor is a single hexadecimal number which represents the value of the next weight compared to the size of the first weight applied to the scale.

The weight factor is arranged as follows:-

1 = The weights are equal.

2 = The next weight is twice as big as the first weight

3 = 3 times as big as the first weight

4 = 4 times...

5 = 5 times ...

6 = 6 times..

7 = 7 times...

8 = 8 times...

9 = 9 times....

A = 10 times...

B = 11 times...

C = 12 times...

D = 13 times...

E = 14 times...

F = 15 times as big as the first weight

*Examples: 30kg scale to be linearized with the weight values shown in brackets:*

*Ex1: 30kg (10kg ,10kg ,10kg)*

Display	Key Press	Note
03 CLn	TARE	Into linearity calibration
L0	TARE	First point (zero), remove weigh pan and press the Tare key
L1 1	TARE	Put 10kg on and press the Tare key
L2 1	TARE	Put 10kg on and press the Tare key
L3 1	TARE	Put 10kg on and press the Tare key
L4 1	NET/GROSS	To finish linearity adjustment (4 points linearity calibration)
03 CLn		

*Ex2: 30kg (5kg, 10kg ,10kg, 5kg)*

Display	Key Press	Note
03 CLn	TARE	Into linearity calibration
L0	TARE	First point (zero), remove weigh pan and press the Tare key
L1 1	TARE	Put 5kg on and press the Tare key
L2 2	TARE	Put 10kg on and press the Tare key, 2 is the rate of L1 (10kg is 2 x 5kg, which was used in L1)
L3 2	TARE	Put 10kg on and press the Tare key
L4 1	TARE	Put 5kg on and press the Tare key
L5 1	NET/GROSS	To finish linearity adjustment (5 points linearity calibration)
03 CLn		



Ex3: 30kg (5kg, 5kg ,10kg, 10kg)

<b>Display</b>	<b>Key Press</b>	<b>Note</b>
03 CLn	TARE	Into linearity calibration
L0	TARE	First point (zero), remove weigh pan and press the Tare key
L1 1	TARE	Put 5kg on and press the Tare key
L2 1	TARE	Put 5kg on and press the Tare key
L3 2	TARE	Put 10kg on and press the Tare key
L4 2	TARE	Put 10kg on and press the Tare key
L5 1	NET/GROSS	To finish linearity adjustment (5 points linearity calibration)
03 CLn		


Ex4: 30kg (1kg, 2kg ,5kg, 10kg, 2kg, 10kg)

<b>Display</b>	<b>Key Press</b>	<b>Note</b>
03 CLn	TARE	Into linearity calibration
L0	TARE	First point (zero), remove weigh pan and press the Tare key
L1 1	TARE	Put 1kg on and press the Tare key
L2 2	TARE	Put 2kg on and press the Tare key
L3 5	TARE	Put 5kg on and press the Tare key
L4 A	TARE	Put 10kg on and press the Tare key
L5 2	TARE	Put 2kg on and press the Tare key
L6 A	TARE	Put 10kg on and press the Tare key
L7 1	NET/GROSS	To finish linearity calibration (7 points linearity calibration)
03 CLn		

- In the process of L0, L1, press [NET|GROSS] key (For approval models, use [NET|B/G] key instead ) to abort the linearity calibration.
- In the process of L2, L3, L4, L5, L6, L7, or L8 press [NET|GROSS] key (For approval models, use [NET|B/G] key instead ) to finish and save the 2, 3, 4, 5, 6, 7, or 8 points calibration.
- In the process of L8, press [TARE|PT] key to finish and save the 9 points calibration.




### 3-3 02 CAL Weight Calibration





### 3-3-1 CAL 01 Weight Calibration Setting






### 3-3-2 CAL 02 Manufacturing Location Gravity Setting

■ The gravity value should be among the value of Equator and Polar.

Equator gravity  $G_E = 9.7803184558 \text{ m/sec}^2$     Polar gravity  $G_P = 9.8321772792 \text{ m/sec}^2$   
Taipei ≈ 9.78914 m/sec<sup>2</sup>    Shanghai ≈ 9.79423 m/sec<sup>2</sup>





## 3-4 06 CGr Local Gravity Setting

06 CGr

Press **TARE|PT** key

9.80000

Enter the gravity value of  
the customer's location.

9.79888

Press **TARE|PT** key

06 CGr

**ZERO** key ⇒ Upward key (0~9 digit entry)

**UNIT** key ⇒ Downward key (0~9 digit entry)

**TARE|PT** key ⇒ Move cursor rightward

**NET|GROSS** key ⇒ Move cursor leftward

(For approval models, use **NET|B/G** key instead)

**The gravity value should be among the value of Equator and Polar.**

Acceleration of gravity at the Equator:  
 $G_E = 9.7803184558 \text{ m/sec}^2$

Acceleration of gravity at the Poles:  
 $G_P = 9.8321772792 \text{ m/sec}^2$

Taipei ≈ 9.78914 m/sec<sup>2</sup>

Shanghai ≈ 9.79423 m/sec<sup>2</sup>



## 3-5 04 CFn Function Setting

04 CFn

Press **TARE|PT** key

CFn 00

Input a parameter 00~12

CFn 00

To exit enter "00" and  
press **TARE|PT** key to go  
back to the upper level

04 CFn

- CFn 00 ⇒ Back to the upper level
- CFn 01 ⇒ Environment parameters
- CFn 02 ⇒ Approval configuration
- CFn 04 ⇒ Initial Zero Setting
- CFn 05 ⇒ Hold Function Setting
- CFn 06 ⇒ Zero Tracing Setting
- CFn 07 ⇒ Counting Function Setting
- CFn 08 ⇒ Tare Setting

**ZERO** key ⇒ Upward key (0~9 digit entry)

**UNIT** key ⇒ Downward key (0~9 digit entry)

**TARE|PT** key ⇒ Move cursor rightward


**NET|GROSS** key ⇒ Move cursor leftward

(For approval models, use **NET|B/G** key instead)



### 3-5-1 CFn 01 Environment Parameters

■ If parameters are changed in CFn 01, then FnC 05 will be revised automatically



#### Return to zero

The display shows the last setting

#### Return to zero point

Using **ZERO** or **UNIT** to enter

➤ Default setting = 0

0 ⇒ show all    5 ⇒ within 5 d

1 ⇒ within 1 d    6 ⇒ within 6 d

2 ⇒ within 2 d    7 ⇒ within 7 d

3 ⇒ within 3 d    8 ⇒ within 8 d

4 ⇒ within 4 d    9 ⇒ within 9 d

■ Weight value must over **1/3 full scale**

#### Stabilization range

Display shows the last setting

#### Stabilization range

Use **ZERO** or **UNIT** keys to input the parameters.

➤ Default setting = 0

Parameter 0 ~ 9, the larger the number the more stable the weight.

#### Filter setting

Display shows the last setting.

#### Weighing Filter setting

Use **ZERO** or **UNIT** keys to input the parameters.

➤ Default setting = 5

Range 0 ~ 9, the larger the number, the faster the filter response. Fast response could lead to display weight instability.

Parameter 9 → the AD value is not filtered.  
Input AD value = Output AD value

**ZERO** key ⇒ Upward key (0~9 digit entry)

**UNIT** key ⇒ Downward key (0~9 digit entry)


**TARE|PT** key ⇒ Move cursor rightward

**NET|GROSS** key ⇒ Move cursor leftward

(For approval models, use **NET|B/G** key instead)



### 3-5-2 CFn 02 Approval Configuration



**Approval configuration**  
Display shows last setting


**Approval configuration**  
Use **ZERO** or **UNIT** to input the setting  
0 ⇒ Non-approval models  
1 ⇒ OIML or NTEP approved model,  
2 ⇒ Sri Lanka approved model, zero can be accepted within a range of the zero calibrated point ±3%.  
3 ⇒ Sri Lanka approved model, zero can be accepted within a range of the zero calibrated point ±3%.  
4 ⇒ Brazil approved model.  
5 ⇒ Approved model. In the tare mode, the gross weight will be displayed after pressing the **NET/GROSS** key. After 5 seconds, the net value will be displayed automatically.  
6 ⇒ Philippines non-approval model  
7 ⇒ Burma non-approval model. In RS232 mode, the unit "viss" is available.

**ZERO** key ⇒ Upward key (0~9 digit entry)  
**UNIT** key ⇒ Downward key (0~9 digit entry)  
**TARE|PT** key ⇒ Move cursor rightward  
**NET|GROSS** key ⇒ Move cursor leftward  
(For approval models, use **NET|B/G** key instead)

巴西批准模型：在计数模式下，如果单件重量小于0.1e，计算器无法计算计数值，将显示“-----”。



### 3-5-3 CFn 04 Initial Zero Setting



#### Zero range setting at switch on

LCD displays the last setting

#### Initial Zero Setting

Use **ZERO** or **UNIT** key to enter the setting  
Default setting = 0 (**OIML** or **NTEP** approval model)  
Default setting = 9 (Non-approval model)

- 0 ⇒ ± 10% full scale
- 1 ⇒ ± 20% full scale
- 2 ⇒ ± 30% full scale
- 3 ⇒ ± 40% full scale
- 4 ⇒ ± 50% full scale
- 5 ⇒ ± 60% full scale
- 6 ⇒ ± 70% full scale
- 7 ⇒ ± 80% full scale
- 8 ⇒ ± 90% full scale
- 9 ⇒ ± 100% full scale

**ZERO** key ⇒ Upward key (0~9 digit entry)  
**UNIT** key ⇒ Downward key (0~9 digit entry)  
**TARE|PT** key ⇒ Move cursor rightward  
**NET|GROSS** key ⇒ Move cursor leftward  
(For approval models, use **NET|B/G** key instead)


■ OIML or NTEP approval model (CFn 02 setting is "1"), and the initial zero setting is: ± 10% of full scale

Non-approval model (CFn 02 setting is "0"), and the initial zero setting is: ± 100% full scale



### 3-5-4 CFn 05 Hold Function Setting

When CFn 02 =1 (OIML or NTEP approval), CFn 05 must set to hoLd=0.



#### Hold function setting

Display the last used value

Use **ZERO** or **UNIT** keys to select 0~5

➤ Default setting = 0

0 ⇒ Hold function disabled

1 ⇒ "Peak hold" mode

2 ⇒ "Stable hold 1" mode

3 ⇒ "Stable hold 2" mode

4 ⇒ "Animal scale hold 1" mode

5 ⇒ "Animal scale hold 2" mode

**ZERO** key ⇒ Upward key (0~9 digit entry)

**UNIT** key ⇒ Downward key (0~9 digit entry)

**TARE|PT** key ⇒ Move cursor rightward

**NET|GROSS** key ⇒ Move cursor leftward

(For approval models, use **NET|B/G** key instead)

hoLd 0 = Hold is disabled

hoLd 1 = "Peak hold" mode: Hold peak weight on the display until a key is pressed to release hold and get a new peak weight.

hoLd 2 = "Stable hold 1" mode: When the weight is stable, Hold the current stable weight until a key is pressed to release hold and get a new stable weight.

hoLd 3 = "Stable hold 2" mode: When the weight is stable, Hold the current stable weight until weight returns to zero (<10d), the hold is cancelled automatically.

hoLd 4 = "Animal scale hold 1" mode


When no load, display "----". After the animal is on the platter and the weight is stable, the display Hold the current stable weight value. When the animal is off the platter, the display "----" and the hold is released. If the weight is hardly stable, display Hold the average weight in 10 seconds until the weight < 10e and display shows "----" or press any key to calculate a new weight.

hoLd 5 = "Animal scale hold 2" mode


When no load, display "0.000". After the animal is on the platter and the weight is stable, display Hold the current stable weight value. When the weight added or removed on the platter is > the hold range set in hold 5, hold is released and calculate a new hold weight. If the weight is hardly stable, display Hold the average weight in 10 seconds. **ZERO** and **TARE|PT** keys are inactive here. The locking speed can be set through the SPEEd setting in hold 5. "1" is the fastest and "5" is the slowest



## Animal scale hold 1 hold 4



## Animal scale hold 2 hold 5



**ZERO** key ⇒ Upward key (0~9 digit entry)

**UNIT** key ⇒ Downward key (0~9 digit entry)

**TARE|PT** key ⇒ Move cursor rightward

**NET|GROSS** key ⇒ Move cursor leftward

(For approval models, use **NET|B/G** key instead)

When weight returns to zero, Hold is released

After weight is HOLD, Hold is released only when weight change is more than  $\pm$  Hold range.

For example: if Hold range = 1 kg. Weight is held at 8.5kg after buzzer sounds.

When weight changes outside the range of  $8.5 \pm 1$ kg, for example, when weight is  $> 9.5$ kg or  $< 7.5$ kg, HOLD is released and until new HOLD weight is re-captured (displays weight changes until it enters HOLD).

Repeat to test the same animal for more than 10 times to compare the errors. Then finalize the Hold speed and Hold range setting.



### 3-5-5 CFn 06 Zero Tracking

The diagram shows the following sequence of displays:

- CFn 06
- Press TARE|PT key → E - EC 0
- Press TARE|PT key → CFn 06

#### Zero tracking setting

Display the last used value  
Use **ZERO** or **UNIT** keys to key in the parameters  
 ➤ Default setting = 0  
 0 ⇒ Enable zero tracking  
 1 ⇒ Disable zero tracking

### 3-5-6 CFn 07 Counting Function Setting

The diagram shows the following sequence of displays:

- CFn 07
- Press TARE|PT key → PCsoFF
- Press TARE|PT key → CFn 07

#### Counting Function Setting

Display the last used value  
Use **ZERO** or **UNIT** keys to select  
 ➤ Default setting = On  
 on ⇒ Enable Counting Function  
 oFF ⇒ Disable Counting Function

☞ After setting is complete, the initial turn on unit will return to the first unit.

<b>ZERO</b> key ⇒ Upward key (0~9 digit entry)
<b>UNIT</b> key ⇒ Downward key (0~9 digit entry)
<b>TARE PT</b> key ⇒ Move cursor rightward
<b>NET GROSS</b> key ⇒ Move cursor leftward
(For approval models, use <b>NET B/G</b> key instead)

### 3-5-7 CFn 08 Tare Setting

The diagram shows the following sequence of displays:

- CFn 08
- Press TARE|PT key → Frq 2
- Press TARE|PT key to save → -nt 1
- Press TARE|PT key to save → CFn 08

#### Tare Setting

Display the last used value  
Use **ZERO** or **UNIT** keys to select 0~2.  
 ➤ Default setting = 2  
 0 ⇒ Disable tare  
 1 ⇒ Tare only once  
 2 ⇒ Continuous tare

#### Negative Tare

Display the last used value  
Use **ZERO** or **UNIT** keys to select 0~1.  
 ➤ Default setting = depending on which CFn 02 approval parameter selected.  
 0 ⇒ Prohibited  
 1 ⇒ Allowed

☞ Defaults for non-approval: continuous tare (Frq=2) and negative tare is allowed (-nt=1)  
 ☞ Defaults Approval: tare only once (Frq=1) and negative tare is prohibited (-nt=0)



## Appendix 1 ASCII Code Table

	0	1	2	3	4	5	6	7	8	9	
ASCII	30H	31H	32H	33H	34H	35H	36H	37H	38H	39H	
	A	B	C	D	E	F	G	H	I	J	K
ASCII	41H	42H	43H	44H	45H	46H	47H	48H	49H	4AH	4BH
	L	M	N	O	P	Q	R	S	T	U	V
ASCII	4CH	4DH	4EH	4FH	50H	51H	52H	53H	54H	55H	56H
	W	X	Y	Z	a	b	c	d	e	f	g
ASCII	57H	58H	59H	5AH	61H	62H	63H	64H	65H	66H	67H
	h	i	j	k	l	m	n	o	p	q	r
ASCII	68H	69H	6AH	6BH	6CH	6DH	6EH	6FH	70H	71H	72H
	s	t	u	v	w	x	y	z			↔
ASCII	73H	74H	75H	76H	77H	78H	79H	7AH			0DH

## Appendix 2 7-Segment Display Characters

0	1	2	3	4	5	6	7	8	9	
A	B	C	D	E	F	G	H	I	J	
K	L	M	N	O	P	Q	R	S	T	
U	V	W	X	Y	Z					



## Appendix 3 RS-232 Data Format

### ■ Command Mode

On RS485 command mode, the format is as following,

1. If RS485's ID setting is 0(RS1 12), and the command is the same as regular RS232.
  2. A. If RS485's ID setting is not 0(assume 99),"@ID" has to be added in front of every command. If you wish to command a zero-return, the complete command is @99MZY, then press "ENTER" key
  - B. If there is an error on entered command, letter "E" will show up + "Unidentified Command"
- e.g.** @99MZZ  
The response message is => 99E1MZZ
3. RS485 responses only to machines of identified ID code

### Command Format A

Host	Command
Slave	Command

MZ	Zero	SO	Command mode
MT	Tare	UA	Switch to the first unit
MG	Gross weight	UB	Switch to the second unit
MN	Net weight	UC	Switch to the third unit
CT	Clear TARE value	UD	Switch to the forth unit
SC	Continuous transmission	UE	Switch to the fifth unit
SA	Auto transmission	UF	Switch to the sixth unit
%	Stop continuous transmission and enter the command mode		

**Note:** UA ~ UF settings are depended on the model of the scale

If continuous "SC" or automatic "SA" transmission is used, to change back command mode, please input "%" and press the enter key before sending the next data.

Note: rs1 05 can modify the number data per second.

### Command Format B

Host	Command
Slave	Data

RW	Read current weight	RH	Read Gross (simple)
RG	Read Gross weight	RI	Read Net (simple)
RN	Read Net weight	RJ	Read comparison situation + current display of weight (simple)
RT	Read TARE	RK	Read comparison situation + Gross (simple)
RB	Read current display of weight (simple)	RL	Read comparison situation + Net (simple)
RZ	Print F-M 13 Brazil format		

**Note:** a. add % before the command to read continuously

b. add # before the command to transmit a stable value



## RJ,RK,RL Command Description

If RL command entered, and

if weight is higher than HI (FNC 03 setting), and if the current weight is 10 kg, the following will be displayed: "100+ 10.000"

If weight is higher than HI (FNC 03 setting), and if the current weight is 0.5 kg, the following will be displayed: "001+ 0.500"

If weight is between HI and LOW, and if the current weight is 1 kg, the following will be displayed: 010+ 1.000

### Read weight comparison setting value RS○○□□

○○: Groups(00 ~ 09) □□: Setting Items

<b>HI</b>	<b>Show "HI" presetting value</b>
<b>LO</b>	<b>Show "LO" presetting value</b>

**Note :** ○○(Group) is various depended on different models

00 ⇒ The first group

01 ⇒ The second group

02 ⇒ The third group

⋮ ⋮ EX: RS02LO<CR><LF> Show "LO" presetting value

ANS: RS02LOXXXXXX<CR><LF>

## Command Format C

Host	Command+ Data
Slave	Command+ Data

### Write weight comparison setting value WS○○□□XXXXXX

○○: Groups(00 ~ 09) □□: Setting Items XXXXXX: Setting Value

<b>HI</b>	<b>Write "HI" setting value</b>
<b>LO</b>	<b>Write "LO" setting value</b>

**Note :** ○○ (Group) is various depended on different models

00 ⇒ The first group

01 ⇒ The second group

02 ⇒ The third group

⋮ ⋮

EX: WS00HI001000<CR><LF> Write "HI" setting value

ANS: WS00HI001000<CR><LF>

## Set pre-tare weight value:

PT,○○○○○○<CR><LF> (○○○○○○means weight)

To set pre-tare weight of 1kg while zero display as 0.000kg, give the following commands:

PT,001000

To cancel pre-tare, give the following commands: PT,000000

## Error messages:

ND means the weight value is not in valid divisions

If the Scale's division is 5, the last digit of weight input must be 5 or 0.

NG means the weight value is over max capacity


NN means the weight value is non-numeric

**Command Format D**

Host	Data
Slave	

Value (e.g. Price)						Position of decimal point	CR	LF
1	2	3	4	5	6	1		

When the Slave receives this data format, it will transfer the data and display it on its LCD.



- The function is effective when the weight value is over 0.
- The above 4 (ABCD) command formats are RS232 bi-directional. There are the following error messages received by Slave terminal (scale).

Error messages:

- E1: Wrong command
- E2: Command format error (Wrong parameters)
- E3: Command not recognised

**□ Output data format****1. 7 places (first decimal place not included)****Weight format**

Gross	S	T	,	G	S	,	+	0	1	2	3	4	5	6	7	SP	SP	o	z		
Net	S	T	,	N	T	,	+	1	.	2	3	.	4	5	6	t	l	.	g		
Tare	S	T	,	T	R	,	+	0	1	2	.	3	4	5	6	SP	SP	k	g	CR	LF
Plus OL	O	L	,	G	S	,	+	SP													
Minus OL	O	L	,	G	S	,	-	SP													
Unstable	U	S	,	G	S	,	+	0	1	2	3	4	.	5	6	SP	SP	l	b		

**Weight format (OIML)**

Gross	S	T	,	G		,	+	0	1	2	3	4	5	6	7	SP	SP	o	z		
Net	S	T	,	N		,	+	1	.	2	3	.	4	5	6	t	l	.	g		
Tare	S	T	,	T		,	+	0	1	2	.	3	4	5	6	SP	SP	k	g	CR	LF
Plus OL	O	L	,	G		,	+	SP													
Minus OL	O	L	,	G		,	-	SP													
Unstable	U	S	,	G		,	+	0	1	2	3	4	.	5	6	SP	SP	l	b		

**Simple format**

G/N	+	1	.	2	3	.	4	5	6												
G/N	+	0	1	2	3	4	5	.	6												
G/N	+	0	1	2	.	3	4	5	6												
Plus OL	+	SP																			
Minus OL	-	SP																			

**Comparison status + Simple format**

Byte0	Byte1	Byte2	+/-	1	.	2	3	.	4	5	6	CR	LF
-------	-------	-------	-----	---	---	---	---	---	---	---	---	----	----

Byte0 : HI 30H/31H

Byte1 : OK 30H/31H

Byte2 : LO 30H/31H

**2. 6 places ( first decimal place not included)****Weight format**

Gross	S	T	,	G	S	,	+	1	2	3	4	5	6	7	SP	SP	o	z
Net	S	T	,	N	T	,	+	.	2	3	.	4	5	6	t	l	.	g
Tare	S	T	,	T	R	,	+	1	2	.	3	4	5	6	SP	SP	k	g
Plus OL	O	L	,	G	S	,	+	SP										
Minus OL	O	L	,	G	S	,	-	SP										
Unstable	U	S	,	G	S	,	+	1	2	3	4	.	5	6	SP	SP	l	b

CR LF

**Weight format (OIML)**

Gross	S	T	,	G		,	+	1	2	3	4	5	6	7	SP	SP	o	z
Net	S	T	,	N		,	+	.	2	3	.	4	5	6	t	l	.	g
Tare	S	T	,	T		,	+	1	2	.	3	4	5	6	SP	SP	k	g
Plus OL	O	L	,	G		,	+	SP										
Minus OL	O	L	,	G		,	-	SP										
Unstable	U	S	,	G		,	+	1	2	3	4	.	5	6	SP	SP	l	b

CR LF

**Simple format**

G/N	+	.	2	3	.	4	5	6										
G/N	+	1	2	3	4	5	.	6										
G/N	+	1	2	.	3	4	5	6										
Plus OL	+	SP																
Minus OL	-	SP																

CR LF

**Comparison status + simple format**

Byte0	Byte1	Byte2	+/-	.	2	3	.	4	5	6	CR	LF
-------	-------	-------	-----	---	---	---	---	---	---	---	----	----

Byte0 : HI 30H/31H

Byte1 : OK 30H/31H

Byte2 : LO 30H/31H

Switch between old and new (OIML) formats: Press and hold **M+/PRINT** key to turn on the scale, and when the display oLd/nEW appear for 2 seconds, release it to restart the scale nEW (OIML):




Gross	S	T	,	G		,	+	1	2	3	4	5	6	7	SP	SP	o	z
-------	---	---	---	---	--	---	---	---	---	---	---	---	---	---	----	----	---	---

oLd:

Gross	S	T	,	G	S	,	+	1	2	3	4	5	6	7	SP	SP	o	z
-------	---	---	---	---	---	---	---	---	---	---	---	---	---	---	----	----	---	---



## ▣ Serial Data Transfer/Receive Format



Note:

S : Start bit

STOP: Stop bit


P : Parity bit




## Appendix 4 Wiring Instructions

### Load cell wiring method

- (1) As shown below, when a load cell is connected with a 4PIN cable, SEN+ and SEN- can be unconnected. J11 and J12 on PCB must be tin-soldered in short circuit.



- (2) If Load Cell is 6PIN, please wire as the following diagram:





## RS232 wiring instruction

To connect RS232, please open the housing, RS232's PIN connectors locate on the bottom-right corner of the main board. The most common connection method is using 9PIN and 25PIN, as shown below:

PC	PIN	PC PIN Function	Female 9 PINS (PC PIN)	QW/GW PIN	QW/GW
	2	Receive Data (from QW/GW)		TxD	
	3	Transmit Data (to QW/GW)		RxD	
	5	Signal Ground		SG	

Printer	PIN	Printer PIN Function	Male 25 PINS (Printer PIN)	QW/GW PIN	QW/GW
	2	Receive Data (from QW/GW)		TxD	
	3	Transmit Data (to QW/GW)		RxD	
	7	Signal Ground		SG	

## RS485 wiring instruction

To connect RS485, please make J17, J18 short and J15, J16 open on main board.

PC	PIN	PC PIN Function	Female 9 PINS (PC PIN)	QW/GW PIN	QW/GW
	2	Data I/O (half-duplex)		DB	
	3	Data I/O (half-duplex)		DA	
	5	Signal Ground		SG	

Printer	PIN	Printer PIN Function	Male 25 PINS (Printer PIN)	QW/GW PIN	QW/GW
	2	Data I/O (half-duplex)		DA	
	3	Data I/O (half-duplex)		DB	
	7	Signal Ground		SG	

To use other connection methods, please identify the signal and following the above principles. After it is finished, please assemble the housing by the instruction in the *SPECIAL NOTICE*.