

# Waterproof Weighing Indicator GTW User manual

© EXCELL PRECISION CO., LTD. 2022. All rights reserved worldwide.

The information contained herein is the property of EXCELL PRECISION CO., LTD. and is supplied without liability for errors or omissions. No part may be reproduced or used except as authorized by contract or other written permission. The copyright and the foregoing restriction on reproduction and use extend to all media in which the information may be embodied.





6F, No. 127, Lane 235, Baoqiao Rd., Xindian District, New Taipei City 23145, Taiwan

pm-all@excell.com.tw



https://www.excell-scale.com

+886-2-8919-1000



+886-2-8919-2209

# **Table of Contents**

PREPARING TO USE THE SCALE	.2
PRECAUTIONS FOR USE	.2
CHAPTER 1 INTRODUCTION	.4
<ul> <li>1-1 PRODUCTION INTRODUCTION</li> <li>1-2 DISPLAY DESCRIPTION</li> <li>1-3 KEYPAD FUNCTIONS DESCRIPTION</li> <li>1-4 POWER DESCRIPTION</li> <li>1-5 ERROR MESSAGES</li> </ul>	.5 .5 .6
CHAPTER 2 GENERAL OPERATION DESCRIPTION	.6
2-1 BACKLIGHT FUNCTION 2-2 WEIGHING MODE 2-2-1 Units Selection 2-2-2 Zero Function	.7 .7
2-2-3 Tare Function	. 8 . 9 10
2-3-1 Sampling	10 10
CHAPTER 3 GENERAL FUNCTION SETTING 1	
3-1 F4 CHECK WEIGHING CONFIGURATIONS       1         3-2 F5 RS-232 OUTPUT SETTING (OPTION)       1         3-3 F6 EXIT FUNCTION       1         3-4 F7 INTERNAL VALUE DISPLAY MODE       1         3-5 F8 WEIGHT HOLD MODE SETTING       1         3-6 F11 ID CODE SETTING       2	13 18 18 18 20
3-7 F12 PRINT KEY ( Function Setting	21 22
APPENDIX 1 OPTION CARD DESCRIPTION2	-
APPENDIX 2 LOAD CELL PIN	<u>2</u> 4
APPENDIX 3 MODBUS DATA ADDRESS TABLE2	<u>2</u> 4
APPENDIX 4 7-SEGMENT DISPLAY CHARACTERS2	25

#### **Check Firmware Version**

Turn on scale and hold ZERO key during countdown. Display firmware version 02018. Turn off scale and turn on scale and hold TARE key during countdown. Display maintenance number 13X where X is ranged from 0~9. Turn off and turn on scale to return to weighing mode. Thank for your purchasing of our EXCELL Weighing Scale. To guide you to use our product correctly, please read this User Manual carefully to extend the life of machine and to avoid error.

# **Preparing to Use the Scale**

- 1. Locate the scale on a firm level surface free from vibrations for accurate weight readings. Adjust the four leveling feet to centre the leveling bubble on the scale.
- 2. Avoid hot sunshine directly on the scale or near the exhaust port of ventilating system.
- 3. Please use a separate power source plug to avoid the disturbance of other electric appliances.
- 4. There should be no weight on the scale when power is turned on.
- 5. Commodity should be placed at the centre of platter when being weighed, and its size should not exceed the dimension of the platter.
- 6. Please warm the scale  $15 \sim 20$  minutes before using.
- 7. Please note that when symbol appears on the screen, the scale needs to be charged.
- 8. Any suggestion is warmly welcome.

# **Precautions for Use**

- 1. Please operate or charge the scale in an open area. Do not squeeze the power cord to avoid wire on fire.
- 2. Please keep scale in a cool and dry place. Do not store under high temperatures.
- 3. Please keep the scale clean and free from insect infestation.
- 4. Avoid impacting with other items or overloaded with excessively heavy weights (The load must not exceed the maximum capacity of the scale).
- 5. If the scale is not going to be used for some time, please clean it and store it in a plastic bag in dry condition. A desiccant sachet may be included to prevent moisture from building up.
- 6. Operating temperature:  $-10^{\circ}C \sim + 40^{\circ}C$
- 7. It is recommended to be used indoors and in environments with a height of less than 2000m
- 8. If the product is used in a manner not specified by the manufacturer, product warranty may be limited.


9. Due to the storage battery adopt the advanced free-maintaining technique, customers need not to replenish electrolyte.

The scale should be recharged every 3 months to prevent failure of the internal rechargeable battery.

- 1. The battery should be charged for 8~10 hours.
- 2. The temperature of battery should below 45°C.

#### Maintaining

- 1. Please do not discharge with over-current when using the battery. Please charge the battery after discharging current.
- 2. Please take down the battery when the scale is not used for a long time or break the connection of cathode.
- 3. Do not short the battery terminals to check whether there is current. Please check whether the connection point is firm to guarantee good connection.
- 4. The battery should be replaced by specialized person. No reverse-battery or the product will be damaged.
  - a) Anode of battery should be connected with Anode of product battery (usually red cable)
  - b) Cathode of battery should be connected with Cathode of product battery (usually brown cable or black cable)



See the picture following C)

# Safety Warnings

- 1. The electrolyte of battery is caustic which causes metal, cotton, etc to corrode.
- 2. The hydrogen will be resolved when using or charging the battery and it will cause explosion when approaches fire.









No Burning


Caution Corrosion Warning Explosion


Children Faraway

# **Chapter 1 Introduction**


# **1-1 Production Introduction**

- 1. IP 68: mist-proof, waterproof and dustproof
- 2. U shape stand or Sleeve connecting stand selectable
- 3. High performance A/D converter
  - 0.3 uv/D high sensitivity
- zero point adjustable range -2mV~ +5mV
- Sampling speed 15 times/second
- use range -4mV ~ +30mV
  load cell stimulate power source 5V DC ±2% 100mA
- 4. According to different resolution to do linearity calibration
  - Ordinary resolution models (below 10000)
     Do specification calibration first then do weight calibration
  - ≻ High resolution models (10000~30000)
     Do linearity calibration first→ specification calibration → weight calibration at last
- 5. LCD display with LED backlight, powered by battery or plug-in mains, automatic power-off function to ensure the stability of the scale. When battery voltage is lower than the system voltage, scale is automatically powered off to ensure the accuracy and stability of the scale.
- 6. Check Weighing function for high limit and low limit and OK range.
- 7. 5 HOLD functions including animal scale HOLD
- 8. Depending on actual space, a RS232 card and/or a relay card can be installed.
- 9. Dimensions: 238 x 156 x 90mm ( W x H x D)





**1-2 Display Description** 



HI	:	High limit value
ОК	•	OK range within HI and LO limits
LO	:	Low limit value
kg	:	"kg" unit
lb	••	"lb" unit
Pcs	:	Counting mode
%	:	Percent indication
$\rightarrow 0 \leftarrow$	••	"Zero" indication
Net	:	"Net weight" indication
	:	"Low battery power" indication

▼1		"Stable" indication
▼2	:	"Pre-tare mode" indication
▼3	:	(M+) "Accumulation mode" indication
▼5	:	(+ ) "Samples insufficient" indication
▼6	:	( $\operatorname{Best}$ ) "Unit weight insufficient" indication
▼7	:	"Viss" unit (Burma unit)

For Dual Range Models, the indicator 5 and 6 will be defined as below:

**▼**6 is Range 1

▼5 is Range 2

# **1-3 Keypad Functions Description**

Press this key to power on or power off the scale	ON
Loop select from the preset units	UNITS
Preset weight and quantity for weight check or quantity check	
Accumulate weight or quantity	M+
Tare to deduct the container weight	\$
Set preset tare	
Recall the totalization value, preset value and pre-tare value	
Clear the totalization value, preset value and pre-tare value.	CE
Zero the scale.	<b>→O</b> -
Press this key to input the numbers $(0 \sim 9)$ and to light up the backlight.	<b>^∕☆</b>
Press this key to print the total data and to confirm	<u>ه</u> ر
Go into counting mode	



Press this key to sample

Pcs

# **1-4 Power Description**

Power	Battery	6V 4Ah Rechargeable battery
FOwer	Plugged in	110V / 220V AC
Power consumption with	No backlight	26 mA
1X350Ω load cell	With backlight	32 mA

#### Low Power Alarm

Please note when the ( ) symbol keeps flashing on the left down corner of the display, the batteries should be recharged.

- When the low battery warning symbol shows up, scale is turned off automatically after 5~10 hours if it is used without backlight (1~2 hours if it is used with backlight). Then scale must be fully recharged, before operating again.
- Please recharge at once when the symbol 🚰 shows in order to keep the weight accuracy.

# 1-5 Error Messages

- $oL \Rightarrow$  Weight exceeds 9d of maximum capacity. (d=division)
- $E1 \Rightarrow$  Zero value after power on is over +10% FS.
- $\text{E2} \Rightarrow \text{Zero}$  value after power on is less than -10% FS.
- $E4 \Rightarrow$  Unstable zero return, unstable over 10 sec. Press  $\rightarrow 0 \leftarrow$  to leave E4.
- $E6 \Rightarrow$  Zero is too high when calibrating. (over internal value 350,000)
- $E7 \Rightarrow$  Zero is too low when calibrating. (under internal value 80,000)
- $E10 \Rightarrow$  The scale is not in level status.(only available with level detector equipment.)
- ----  $\Rightarrow$  For weight < -20d without tare or pretare device in operation.

#### E10 Level Switch (option)

Make JP102 on PCB board to be open circuited. Then connect signal to CN101 on PCB. When CN101 is open circuited, display shows E10 after 2 seconds and all keys stop working in the mean time. When CN101 is short circuited, display resumes and can continue weighing. If you do not need level switch, make JP102 short circuited.

# Chapter 2 General Operation Description 2-1 Backlight Function

Press  $\boxed{2}$  key to select the display backlight mode:

- bL. Auto ⇒ "Auto Backlight" mode. When the weight is over 10d or any key is pressed, the display backlight will be switched on. When the weight returns to zero (the weight on platform is less than 10d), the display backlight will switch off after 10 seconds.
- bL. On  $\Rightarrow$  Display backlight is on all the time.
- bL. oFF  $\Rightarrow$  Display backlight is off.

# 2-2 Weighing Mode

#### 2-2-1 Units Selection

- 1. After indicator is turned on, use UNITS key to select a unit from kg, lb, tael or viss, as the screen indicated.
- 2. The selected unit will be memorized when you turn the indicator off. And the memorized unit will appear after you turn on the indicator next time.

#### 2-2-2 Zero Function

Press  $\rightarrow 0+$  key to re-zero the display with no load on the platter. When zero is set, the ( $\rightarrow 0+$ ) symbol will be displayed.

#### 2-2-3 Tare Function

1. When the weight of the container is unknown (  $\Rightarrow$  )

- Place the container on the platter, after stable and press key, the weight value returns to zero and net indication (Net) is on.
- Place goods into the container, then the indicator shows the net weight of goods.

#### Clear tare value

When removing the container and goods, the display shows the negative weight value of the container. Then press key to clear tare value. The indicator returns to zero and net indication (Net) is on.

A Recall tare value

Press  $| \bullet \otimes |$  then  $| \bullet \otimes |$  key  $\Rightarrow$  the display shows tare value

Multiple tare operation  $\Rightarrow$  Users can continuously increase or decrease the tare value by pressing the 4 key.

The total tare value (tare value + pre-set tare value) can equal the full capacity of the indicator.

- 2. When the weight of the container is known (
  - Press → key and the display shows > □ = - □.
     Use → and 
     keys to input weight value of the container. After finishing the procedures, the net indication (Net) and pretare (PT) indication " " is on.
  - Place goods into the container, then the indicator shows the net weight of goods.
  - Clear pretare value

Press  $\checkmark$  then  $\checkmark$  key, and then press **CE** key to clear pretare value. When indicator returns to zero, net indication (**Net**) and pretare (PT) indication " $\checkmark$ " are off.

#### A Recall pretare value

Press  $| \bullet \otimes |$  then  $| \bullet \otimes |$  key  $\Rightarrow$  the display shows pretare value

- In Tare mode, the Preset tare function is disabled.
- The indicators with two weighing ranges can NOT pre-set the tare value larger than the first weighing range. For example: a 30 kg indicator is set by two weighing ranges. The first range is 0 to 15 kg, and the second range is 15 to 30 kg. The pre-set tare value can not be larger than 15 kg.

EXCELL PRECISION CO., LTD. 2-2-4 Check Weighing Mode 1. Preset "High limit", "Low limit" and "Beeper value" operation Use 2 and 2 key to preset values. For example: Preset "Low limit" (Low limit >10d) e.g. Low limit = 20 kg  $\overline{}$ Press kev the display shows 🗧 🛄 Press key 1 time the display shows key 2 times the display shows ÷Г Press Press key 4 times the display shows Preset "High limit" (High limit ≥ Low limit) e.g. High limit = 25 kg Press key 1 time the display shows key 1 time Press the display shows ∕∕ÿ key 2 times the display shows Press Press key 1 time the display shows Press key 5 times the display shows Press key 3 times the display shows Preset "Beeper value" (Refer to Note) e.g. Beeper value = 22 Press key 1 time the display shows ∕∕ÿ key 2 times the display shows ÷ Press Press key 1 time the display shows key 2 times Press the display shows Press key 1 times the display shows

Preset Single point (preset low limit only):

After "preset low limit" procedures is completed and the display shows  $\Rightarrow \Box \in \neg \neg \neg \neg \neg \neg$ , then press  $\Box$  key again, the display shows  $\Box \cdot \Box \Box \Box \Box$ . This means that the "preset single point" procedure is completed.

#### NOTE

- \_ <u>X X <u>+</u> A B</u>

- A Setting for the status that LCD is on and the beeper beep:
  - 0 = when stable, the beeper beeps and LCD is on.
  - 1 = when stable, the beeper beeps; whether stable or not, LCD is on.
  - 2 = whether stable or not, the beeper beeps and LCD is on.
  - 3 = open warning device: when the weight is higher than HI value and the weight is stable, LCD is on and Relay Card open.
- **B** Setting for the beep status:

0 = No beep

- 1 = OK (when the weight is over Low Limit & under or equal to High Limit.), the beeper beeps.
- 2 = When the weight is under or equal to Low Limit & over High Limit, the beeper beeps.

Under Status in Preset Low Limit (preset single point only) The BEEP, LCD mode should be fixed as follows:

 $\downarrow$   $\downarrow$  When over "Low Limit", the beeper beeps and  $\downarrow$  is off Whether stable or not, the beeper beeps and LCD indication is on

Warning device setting

h

Set HI value and value of the beep, LCD mode should be fixed as follows:

When the weight equals to HI value, Relay Card open and the weight is accumulated. Press CE key to dismiss the warning sound and the range of accumulated weight is [000.000]~[999999].

- Press key first and then press **CE** key to clear all accumulated data.
- Accumulated data is cleared automatically under following conditions
   when shift among weight mode, counting mode and warning accumulation
  - a. when shift among weight mode, counting mode and warning accumulation mode. b. when shift the units
  - c. turn off the scale

Set relay low output: L1 => low output; L0=> no low output

- LCD indication:
- ◆ To exit preset mode, please press UNITS key.
  - 2. Recall Check-weighing Values
    - +₽  $\square$ Press kev then press  $\Rightarrow$  Recall "Low limit value" kev Then press key again  $\Rightarrow$  Recall "High limit value" ÷Ð Then press key again  $\Rightarrow$  Recall "Beeper value" €₽ key again Then press  $\Rightarrow$  Back to the beginning
  - 3. Clearing Check-weighing Values

Press $\square$ key then press $\clubsuit$ key, and then press $\square$ key $\Rightarrow$ Recall "Low limit"
value". Then press $\textcircled{CE}$ key again $\Rightarrow$ Clear "High limit value" and "Beeper value"
Press $\square$ key then press $\square$ key 6 times continuously $\Rightarrow$ Clear all values.

#### 2-2-5 Totalizing

1. Weight Totalizing

Place goods on the platter, after stable and press M+ key to save the weight value. Then the display shows the total number of additions and the totalized weight value. And the (M+) indication " $\checkmark$ " will flash on the display. The indicator will recover to show the weight value of the goods on the platter after 3 seconds and the (M+) indication " $\checkmark$ " is on.

- The indicator allows the next totalizing operation, even when the weight value does not return back to zero. The M+ key is functional, when the weight value changes by more than 10d. The indicator will save the totalized weight value after the weight is stable.
- The indicator can totalize positive or negative weight but can't do both at the same time. The totalized weight store must be reset to zero before it is possible to select positive or negative totalizing mode.

- The totalizing function can be used up to a maximum of 9999 times before it must be reset. The totalizing display is limited to 6 digits maximum.
- When totalizing, RS-232 will also output. (Refer to F5 setting)
- 2. Clear Totalized Weight Values
  - ♦ Press + then CE key to clear all totalized weight values.
  - When changing between weighing and counting mode, or selecting weighing unit, the indicator will automatically clear all the totalized weight values.
  - The indicators will automatically clear all the totalized weight values after turning on.
- 3. Recall Totalized Weight Values

Press  $\checkmark$  key to display the total number of additions and the totalized weight value. And the (M+) indication " $\prec$ " will flash on the display. The indicator will return to the weighing mode after 3 seconds.

The indicator will not display the negative sign "-" for negative totalized weight values when recalling a totalized weight value, but when printing, the negative sign "-" will be printed out (transmitted serially) for each negative weight and negative totalized weight.

# **2-3 Counting Function**

#### 2-3-1 Sampling

- Press key to select sample quantity from 10, 20, 50,100
- Select sample quantity and then place samples on the platter, and then press key, the display shows " '\_\_ □ □ □ □ □ □ □.

After stable, the scale enters into counting mode and the display shows sample quantity.

- Sample Too Small (  $\therefore^+$  )  $\Rightarrow$  Sample is less than 20 divisions.
- Unit Weight Too Small  $\left( \begin{vmatrix} c & c \\ Pcs \end{vmatrix} \right) \Rightarrow$  Unit weight is less than 0.2 division.

(0.1 d for Brazil regulation)

- When sampling, the above two symbols indications are on. Under such conditions, the scale can still work, but may result in lower count precision.
- When using 2-segment weighing mode, the above two symbol indications change to Range 2 and Range 1 and the two symbol indications are off.

#### 2-3-2 Check Weighing


Refer to the operation of check weighing in weighing function.

#### 2-3-3 Totalizing

Refer to the operation of totalizing in weighing function.


# **Chapter 3 General Function Setting**

Switch on the scale. While the scale is counting down to zero, press and hold →0+ key until the display shows the software version number 02018. Release the →0+ key, the scale enters into the configuration setting mode and display F0.




F4	Check Weighing Configurations
F5	RS232 Output Setting (Option)
F6	Exit Function
F7	Internal Value Display Mode
F8	Weight Hold Mode Setting
F11	ID Code Setting
F12	Print Key Function Setting
F14	Customized Header Setting
1 14	(r n P 6, r n P 7)

F0~F3, F9, F10, F13, F15 are reserved.




# 3-1 F4 Check Weighing Configurations




# 3-2 F5 RS-232 Output Setting (Option)

- Make J1, J3 on RS232 short circuit, when connecting to computer.
- Use  $\boxed{\searrow}$   $\boxed{\mathbb{B}^{\text{Met}}}$  or  $\boxed{\textcircled{}}$  key to select F5.



- r n P 0  $\Rightarrow$  RS232 command mode.
- r n P 1  $\Rightarrow$  Stable transmission.
- r n P 2  $\Rightarrow$  Continuous transmission.
- r n P 3  $\Rightarrow$  Press  $\textcircled{9}_{\leftarrow}$  key to transmit totalized simple format.
- r n P 4  $\Rightarrow$  Press  $\boxed{\textcircled{P}_{\downarrow\downarrow}}$  key to transmit totalized complete format.
- r n P 5  $\Rightarrow$  Stable transmission in totalizing mode. Same format as (r n P 3).
- r n P 6  $\Rightarrow$  Press P key to transmit simple free format. Please refer to F14.
- r n P 7  $\Rightarrow$  Press event key to transmit complete Free format. Please refer to F14.
- r n P 8  $\Rightarrow$  While use Hold, press  $\left| \textcircled{Q}_{\downarrow} \right|$  key to transmit same format as (r n P 1) and (r n P 2).
- r n P 11  $\Rightarrow$  Print after removing goods (5% mode).
- r n P 12  $\Rightarrow$  Print after removing goods (OK mode).
- r n P 13  $\Rightarrow$  MODBUS function, need to use with F11 ID Code Setting
- r n P 14  $\Rightarrow$  Stable transmission, only weight value is transmitted
- r n P 15  $\Rightarrow$  Enter serial number, reply serial number, weight
- r n P 16  $\Rightarrow$  Continuous transmission with High, Low, Ok status

#### **RS-232 Interface Format**



#### RS-232 Data Format Command mode (r n P 0)

	mma	ana n	iode (	r n P	U)														
Comn	nanc										Function	Re	etu	rn mes	ssage	definition			
С	C T <cr> <lf></lf></cr>									Clear tare	Ν	Ρ	<cr></cr>	<lf> already pre-tared</lf>					
				1								С	Т	<cr></cr>	<lf></lf>	successfu	l		
Μ	Т	<cr></cr>	<lf></lf>								Tare	Ν	Ρ	<cr></cr>	<lf></lf>	already pr	e-tared		
				-								Μ	Т	<cr></cr>	<lf></lf>	successfu	l		
				_								Ν				unstable			
Μ	Ζ	<cr></cr>	<lf></lf>								Zero	Ν	Ρ	<cr></cr>	<lf></lf>	already pr	e-tared		
												Ν	Т	<cr></cr>	<lf></lf>	already ta	red		
												Μ	Ζ	<cr></cr>	<lf></lf>	successfu			
												Ν	Ζ	<cr></cr>	<lf></lf>	outside ze	ro range		
												Ν	S	<cr></cr>	<lf></lf>	unstable			
R	W	<cr></cr>	<lf></lf>								Read Weight	Re	Return weight format as (r n p1)						
				1															
Р	Т	,	0	0	0	1	0	0	<cr></cr>	<lf></lf>	Set pre-tare	Ν	0	<cr></cr>	<lf></lf>	exceed nu digits	imber of		
L	0	,	0	0	0	1	0	0	<cr></cr>	<lf></lf>	Set low limit	Ν	Ν	<cr></cr>	<lf></lf>	non-numeric value			
Н		,	0	0	0	1	0	0	<cr></cr>	<lf></lf>	Set high limit	Ν	G	<cr></cr>	<lf></lf>	over max weight			
												Ν	D	<cr></cr>	<lf></lf>	Increment	d is incorrect		
1	1	b	<cr></cr>	<lf></lf>							Set buzzer	1	1	b	<cr></cr>	<lf></lf>	successful		

Stable transmission (r n P 1), Continuous (r n P 2), Press 🦳 key to transmit (r n P 8)

	<b>.</b>
1. gram as weight uni	T
	L.

	9.0			9													-
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	g
			HE				J				· ^					5 I 	
	AD	,		AD	,	Ŧ				DAT	А		U		Сг		Г

2. kg or lb as weight unit

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	kg/lb
HE	AD	,	HE		,	 				DAT	A			UN	 IT	 CR	 LF	

	HE	EAD1(2 BYTES)		HE	EAD2 ( 2 BYTES )
OL	-	Overload, Under load	TR	-	TARE Mode
ST	-	Display is Stable	NT	-	NET Mode
US	-	Display is Unstable	GS	-	GROSS Mode

DATA (7 or 8 BYTE)

2B ( HEX ) = " + " ( PLUS) 2D ( HEX ) = " - " ( MINUS ) 2E ( HEX ) = " ." ( DECIMAL POINT )

UNI	「(2	、3 or 4 BYTE	)					
kg	=	6B(HEX)	;	67(HEX)				
lb	=	6C( HEX )	;	62(HEX)				
tl.T	=	74(HEX)	;	6C(HEX)	;	2E(HEX)	;	54 ( HEX )
hkg	=	68(HEX)	;	67(HEX)				
viss	=	76(HEX)	;	69(HEX)	;	73 ( HEX )	;	73 ( HEX )

#### Transmission examples: (r n P 2) RS-232 continuous transmission

EXCELL® EXC	ELL PRECIS	ION CO., LTD.
1. The gross	weight (+0.876	6 kg) shows as below, after stable: (no tare or pre-tare mode)
ST,	GS,	+ 0 . 8 7 6 k g <cr> <lf></lf></cr>
HEAD1	, HEAD2 ,	DATA UNIT CR LF
2. The net we	eight (-1.568 lb)	) shows as below without weight stability: (under tare or pre-tare mode)
US,	<u>N</u> T,	-   1 . 5 6 8 I b <cr> <lf></lf></cr>
HEAD1	, HEAD2 ,	DATA UNIT CR LF
Press 🖭	key to trar	nsmit totalized simple format (r n P 3)
S/N	WT/UNIT(kg / 	lb )
0001	1.0000	Service Se
0002	1.0000	Service Se
0003	1.0000	Service Se
0004	1.0000	Service Se
0005	1.0000	Series or M+ key
0005	5.0000	Press vice to print TOTAL
Press 🧐	key to trar	nsmit totalized complete format (r n P 4)
TICKETS	NO. 0001	
G T	1.000kg 0.000kg	⊸ Press
N (3 blank lir	1.000kg	
•		
TICKETS G	NO. 0002 1.000kg	⊸ Press Or M+ key
т	0.000kg	
N (3 blank lir	1.000kg nes)	
TICKETS	NO. 0003	
G	1.000kg	⊸ Press Or M+ key
T N	0.000kg 1.000kg	
(3 blank lir	nes)	
TOTAL NU	IMBER	$\odot$
OF TICKET	TS 0003	Press
NET	3.000kg	
(3 blank lir	-	TARE N = NET
G=C		



#### Stable Transmission in totalizing mode (r n P 5)

S/N	WT/UNIT(kg / lb)		
0001	1.0000	Ð	The scale is stable
0002	1.0000	Ð	The scale is stable
0003	1.0000	Ð	The scale is stable
0004	1.0000	Ð	The scale is stable
0005	1.0000	Ð	The scale is stable
0005	5.0000	Ð	Press Livice to print TOTAL

### Press key to transmit simple free format (r n P 6)

Same format as (r n P 3). Print the complete format for the first time. Then only print NET weight. Please refer to F14 for details.

# Press key to transmit complete free format (r n P 7)

Same format as (r n P 4). Print the complete format all the time. Please refer to F14 for details.

While use Hold, press **O** key to transmit (r n P 8)

If there is only RS-232, press to print out the HOLD value on the display in HOLD MODE.

#### Print after Removing Goods (5% mode) (r n P 11)

Stage	Condition(s)	Action(s)
1: Goods placed	Weight has become stable.	Beeper beeps twice, and
and weighed on	Weight > zero point	printing data (stable weight
platter	Weight ≥ 20 weighing units	compliant with conditions on
	(i.e. 5% x Weight ≥ 1 weighing unit)	the left) is ready to be sent.
2: Just removed	Instantaneous weight reading drops	Printing data of Stage 1 is
goods from platter	below 95% of last stable weight (stable	sent to the printer (same
	weight of Stage 1)	printing formats as those of
		(r n P 1).

#### Print after Removing Goods (OK mode) (r n P 12)

Stage	Condition(s)	Action(s)
1: Goods placed	Weight has become stable.	Beeper beeps twice, and
and weighed on	Weight > zero point	printing data (stable weight
platter	Check weighing <b>OK</b> status (within a	compliant with conditions on
	predetermined weight range)	the left) is ready to be sent.
2: Just removed	Instantaneous weight reading drops	Printing data of Stage 1 is
goods from platter	below 95% of last stable weight (stable	sent to the printer (same
-	weight of Stage 1).	printing formats as those of
		(r n P 1).

#### r n P 13 $\Rightarrow$ MODBUS Function, Use with F11 ID Code Setting

Formats as in r n P 1 (stable), r n P 2 (continuous), r n P 8 (key), please refer to F11 for details.

EXCELL® EX	KCELL PRECISION CO., LTI	D.		
Stable T	ransmission Only Weight	Value Is Transn	<b>nitted (</b> r n P 14)	
No +/ If (	display is 1.000kg , transmit	1	. 0 0	0 <cr> <lf></lf></cr>
			DATA	CR LF
Enter the	$\Rightarrow$ Enter Serial number, Respectively serial number (up to 64 character 1.000kg, etc. After stable, RS232	s), if you enter the	SN number: SN00	<b>t</b> 01 <cr><lf>, if</lf></cr>
The contin and the se	⇒ Continuous Output Conuous output format is similar to record code output includes High(Horizont to 1.000kg, then 0.876 kg output) , G O , + $($ HEAD2 ,	n p 2, the first code H), Low(L), Ok(O) s t is as follows.	e of HEAD2 is gros	to 0.500kg and
F5	Function	Press M+ key	Press 🙆 key	Press twice after zeroing
rnp 0	RS232 command mode	Once received read same format as r n	d weight command, t p 1.	transmit weight in
rnp 1	Stable transmission	After return to zero,	, transmit next stable	e weight.
rnp 2	Continuous transmission.	RS232 transmit cor	ntinuously. Keypad h	as no effect.
rnp 3	Press key to transmit totalized simple format	Transmit when weight change >±10d,	Transmit when weight change >±10d,	Print TOTAL and clears totalized values
rnp 4	Press key to transmit totalized complete format.	Transmit when weight change >±10d,	Transmit when weight change >±10d,	Print TOTAL and clears totalized values
rnp 5	Stable transmission in totalizing mode (After return to zero, transmit next stable weight which is > +10d)	No transmission	No transmission	Print TOTAL and clears totalized values
rnp 6	Press key to transmit simple free format	Transmit when weight change >±10d,	Transmit when weight change >±10d,	Print TOTAL and clears totalized values
rnp 7	Press key to transmit complete free format	Transmit when weight change >±10d,	Transmit when weight change >±10d,	Print TOTAL and clears totalized values
rnp 8	While use Hold, press to transmit same format as (r n P 1) and (r n P 2)	No transmission	Transmit as stable weight >±10d	No transmission, totalized values not cleared
rnp 9	Continuous Transmission (Brazil)	Continuous transmission	Continuous transmission	Continuous transmission, totalized values not cleared
r n p 10	M+ or key Transmission (Brazil)	RS232 transmit	RS232 transmit	Print TOTAL and clears totalized values
r n p 11	Print after removing goods (5% mode)		nd become stable, b at after item is remov	

F5	Function	Press M+ key Press O key Press key twice after zeroing						
r n p 12	Print after removing goods (OK mode)	RS232 transmit only "OK" item weight after item is removed. No transmission while in "HI" or "LO".						
r n p 13	MODBUS Function	Use MODBUS to transmit weight, and need to use with F11 ID Code Setting,						
r n p 14	Stable transmission, only weight value is transmitted	After return to zero, transmit next stable weight's weight value only.						
r n p 15	Enter serial number, reply serial number, weight	Enter serial number and put the weight on. Once it is stable, return serial number and weight						
r n p 16	Continuous Output Contains High, Low, Ok Status	RS232 transmit continuously containing High, Low, Ok Status. Keypad has no effect.						

<CR>=ASCII carriage return character, hexadecimal is 0D.

<LF>=ASCII line feed character, hexadecimal is 0A.


# 3-3 F6 Exit Function

Use  $\swarrow$  or  $\circledast$  to select F6. Then press  $\bowtie$  to count down to zero and exit the setting.

# 3-4 F7 Internal Value Display Mode

Use  $\swarrow$  or to select F7. Then press  $\checkmark$  to display internal value. Press  $\checkmark$  again will see F7.

# 3-5 F8 Weight Hold Mode Setting



• Before setup, please switch the SWA1 on MINI JUMPER to ADJ position

♦ After setup, please switch the SWA1 on MINI JUMPER back to LOCK position

In hold mode, press key, to print the hold value as shown on display.

(It's not related to the settings of F5 transmission mode, but it needs to select the proper Baud rate according to the transmission of the receiver.)

(To setup transmission rate, please refer to F5 RS-232 Interface Output Setting (option))

Use  $Met \\ B/G$  key to select a value from

hold 0 ~ hold 5 and then press key to complete setup.

hold 0 = No hold function

hold 1 = For varying weighing value, the scale will automatically hold the maximum weighing value to  $\boxed{\bigcirc \checkmark}$ 


display. To exit hold mode, press any key (except the key).

hold 2 = After the scale is stabilized, the scale will automatically hold the display value( not changeable

due to external variables)To exit hold mode, press any key.( except the key )

- hold 3 = After the scale is stabilized, the scale will automatically hold the display value( not changeable due to external variables). After zero return ( or weight is less than 10d), the scale exits the hold mode automatically.
- hold 4 = Animal Scale function. When animal is on the scale platter and is stable, the scale will automatically hold the display value (not changeable due to external variables). After the animal is off the scale platter, the scale exits the hold mode automatically.
- hold 5 = Animal Scale hold function 2. Initially scale displays "0.000" on empty load. When animal is on the scale platter and is stable, the scale will automatically hold and lock the display value (not changeable due to external variables). When weight change (increment or decrement) exceeds the defined "weight hold range", the scale exits the hold mode and recalculates weight. If weight is unstable, the average weight value will be displayed and held for 10 seconds.

#### Animal Scale Hold Setup (hold 4)



#### Animal Scale Hold Function 2 (hold 5)

If How to activate  $\Box \Box \Box \Box = \Box \Box = -$  "Brazilian" Animal Scale Hold Function:

- 1. Select **HOLD 5** in **F8** menu. Set the Weight Hold Range (during weight hold, when weight deviation [positive or negative] exceeds Weight Hold Range, the scale exits the hold mode).
- 2. Display returns to weighing mode. Place an animal (pig, dog, cow, etc.) on the scale. After the buzzer beeps, weight hold is complete.
- 3. Now you can try adding additional weight within Weight Hold Range to test if the weight still holds correctly. Or you can remove all weight(s) to verify that the hold mode exits automatically.


4. Repeat above Steps 2-3 to make 10 or more measurements, then compare deviations among these 10 measurements.

How to exit hold mode:

Suppose Weight Hold Range is set as 1.000 kg, and the weight held after stable is 8.543 kg (now the weight is held with buzzer already beeped, weight value will not change), when weight change (increment or decrement) equals or exceeds Weight Hold Range (i.e. 8.543kg + 1.000kg or 8.543kg – 1.000kg), scale will automatically exit hold mode, then scale will recalculate holding weight (i.e. changing weight is displayed in real time until weight becomes stable, and scale enters hold mode). This whole hold mode entry and exit process will repeat continuously.

### 3-6 F11 ID Code Setting

(must be used with r n P 1, r n P 2, r n P 8 of F5)




#### **RS232 DATA FORMAT**

Stable transmission (r n P 1), Continuous (r n P 2), Press key to transmit (r n P 8) 1. e.g. Machine ID code is 10.

The gross weight (+0.876 kg) shows as below, after stable: (no tare or pre-tare mode)

1	0	S	Т	,	G	S	,	+	0	0	0		8	7	6	k	g	<cr< th=""><th>&gt; <lf></lf></th></cr<>	> <lf></lf>
	ر	$\subseteq$		,	$ \frown $	$\longrightarrow$		$\sim$	-						ノ、	<u> </u>		,	
IC	)	HΕ	AD1	,	HE	AD2	,				DA	TA				UN	IT		
2.	e.g.	Mach	nine	ID co	ode is	s 00.	(Not	usin	g Ma	achin	e ID	func	tion.)	)					
															der	tare o	or pi	re-tare	mode)
U	S	,	Ν	Т	,	-	0	0	1		5	6	8	Ι	b	<cr< td=""><td>l&gt; &lt;</td><td><lf></lf></td><td></td></cr<>	l> <	<lf></lf>	
	γ	)	Ĺ		i		$\mathcal{I}$			~				$\Box$	γ <u> </u>	)			
ப	EAD1		니드	AD2.						DATA				1.11	TIV				

# 3-7 F12 Print Key (<sup>®</sup>) Function Setting




# 3-8 F14 Customized Header Setting (r n P 6, r n P 7)

CODE	Description	CODE	Description
0	No print.	5	Ν
1	TICKET NO.	6	P/N
2	G	7	S/N
3	Т	8	DATE (Note: need FB530's MINI_PRINTER to print)
4	PT	9	TIME (Note: need FB530's MINI_PRINTER to print)

F14 contains a 9-digit code. For example: 6 1 2 3 4 5 0 0 0

① F5 = r n P 6 Simple Free Format

② F5 = r n P 7 Complete Free Format



After power-off, S/N will reset as 1. P/N will be saved in memory, available during next power-on.

# **Appendix 1 Option Card Description RS232** Output

GTW's RS232 cable connect to CN12 of mainboard

PC	PIN	PC PIN Function	Female 9 PINS (PC PIN)	GTW CN12 PIN	GTW
	2	Receive Data (from GTW)	(2)	TxD (2)	GTW .
	3	Transmit Data (to GTW)	$\implies \qquad \bigcirc 9 \circ 6 \circ 7 \circ 6 \qquad (3) \qquad \qquad$	RxD (1)	
[ <u>1</u> ]	5	Signal Ground		SG (5)	
Printer	PIN	Printer PIN Function	Male 25 PINS (Printer PIN)	GTW CN12 PIN	GTW
Printer	PIN 2		(2)	-	GTW
Printer		Function Receive Data		CN12 PIN	

Please refer to F5 function settings for transmission mode, baud rate setting and data format.

#### **Relay Output**

Principle of Relay operation

Use checkweighing pre-set *related* key or though F4 from the menu to get in checkweighing mode to set the HIGH and LOW limit points. Between HIGH and LOW limits are OK range. If the weight is below LOW limit, the data will output in LOW port;

If the weight is between HIGH and LOW limits (OK range), the data will output in OK port; If the weight is above HIGH limit, the data will output in HIGH port

> mainboard PIN 1 – BAT 1 PIN 2 – DVDD PIN 3 – OK PIN 4 – Hi PIN 5 – Lo

CN3 (3 pin) C1

C2

COM

Below are welded directly to CN1 and CN11 of the

A-Lo

B-Lo

COMMON

key and F4 function. Please refer to the operation of Pre-set

GTW Relay Card's PIN definitions and connection method.

GTW RELAY card's power can only be supplied by the system itself

	CN3 CN2 COM C2 C1 B2 B1 A2 A1	
1 2 3 4 5		•


CN2 (4 pin)		
A1	A-HI	
A2	B-HI	
B1	A-OK	
B2	B-OK	

J1 short  $\Rightarrow$  B2 connect to COM J2 s J3 short


short $\Rightarrow$ A2 connect to COM	
short $\Rightarrow$ C2 connect to COM	



# Appendix 2 Load Cell PIN



5-pin female connector



1	EXC+
2	EXC -
3	SIG+
4	SIG -
5	GND

# Appendix 3 MODBUS Data Address Table

Data	Register		Bit I/O	Bit I/O		
Function C	ode 03 (Read)	Functi	on Code 01 (Read)	Function Code 05 and 15 (Write)		
Modbus SCALE		Modbus	SCALE Output	Modbus	SCALE Input	
40004 ~ 40005	As display value	00000	Stable status	01000	Zero	
		00001	Zero status	01001		
Function Code 06 and 16 (Write)		00002	Gross	01002	Tare	
41000 ~ 41001	Pre-tare value	00003	Net	01003	Clear tare	
41014 ~ 41015	LO limit value	00059	Hi			
41018 ~ 41019	HI limit value	00060	Ok			
		00061	Lo			

#### MODBUS Data Address Table II (For Hitech and Pro-face Human Machine Interface)

Data	Register		Bit I/O	Bit I/O			
Function C	ode 03 (Read)	Functi	on Code 01 (Read)	Function Code 05 and 15 (Write)			
Modbus	SCALE	Modbus	SCALE Output	Modbus	SCALE Input		
40005 ~ 40006	As display value	00001	Stable status	01001	Zero		
		00002	Zero status	01002			
Function Code	06 and 16 (Write)	00003	Gross	01003 Tare			
41001 ~ 41002	Pre-tare value	00004	Net	01004	Clear tare		
41015 ~ 41016	LO limit value	00060	Hi				
41019 ~ 41020	HI limit value	00061	Ok				
		00062	Lo				

# Appendix 4 7-Segment Display Characters

									-
0	1	2	3	4	5	6	7	8	9
А	В	С	D	ш	F	G	H	-	J
K	L	М	Ν	0	Р	Q	R	S	Т
U	V	W	Х	Y	Z				